

The Big Book Of ODIS



Quick Review of how to read Volkswagen and Audi Factory wiring diagrams.

The following list shows the German abbreviations to the English text for the most common colors.

bl.	Blue
br.	Brown
ge.	Yellow
gn.	Green
ro.	Red
sw.	Black
li.	Violet
ws.	White

DIN standards for terminal designations

The following are examples of the common Volkswagen DIN list for terminal designations:

- 1 Ignition coil, ignition distributor - Low voltage
- 1a To contact breaker I (Ignition distributor with two separate circuits)
- 1b To contact breaker II (Ignition distributor with two separate circuits)
- 4 Ignition coil, ignition distributor - high voltage
- 4a From ignition coil I (Ignition distributor with two separate circuits)
- 4b From ignition coil II (Ignition distributor with two separate circuits)
- 15 Switched (+) downstream of battery (output of ignition/driving switch)
- 15a Output at ballast resistor to ignition coil and starter
- 17 Glow plug and starter switch - Start
- 19 Glow plug and starter switch - Preheat
- 30 Input from battery (+) term., direct 12/24 V series-parallel battery switch
- 30a Input from (+) terminal of battery II
- 31 Battery negative terminal, or ground, direct
- 31b Return line to battery negative terminal, or ground via switch or relay (switched negative)
- 31a Return line to battery II, negative (12/24 V series-parallel battery switch)
- 31c Return line to battery I, negative (12/24 V series-parallel battery switch)

Electric motors

- 32 Return line
- 33 Main terminal connection
- 33a Self-parking switch-off
- 33b Shunt field
- 33f For second lower-speed range
- 33g For third lower-speed range
- 33h For fourth lower-speed range
- 33L Counterclockwise rotation
- 33R Clockwise rotation

Starters

- 45 Separate starter relay, output; starter, input (main current)
Two-starter parallel operation - Starting relay for engagement current
- 45a Output, starter I, Input, starters I and II
- 45b Output, starter II
- 48 Terminal on starter & on start-repeating relay for monitoring starting

Turn-signal flashers (pulse generators)

- 49 Input
- 49a Output
- 49b Output, second circuit
- 49c Output, third circuit

Starter control

- 50 Starter control (direct)
- 50a Series-parallel battery switch - Output for starter control
- 50b with parallel operation of two starters with sequential control
Starting relay for sequential control of the engagement current during parallel operation of two starters
- 50c Input at starting relay for starter I
- 50d Input at starting relay for starter II
- 50e Start-locking relay Input
- 50f Start-locking relay Output
- 50g Start-repeating relay Input
- 50h Start-repeating relay Output

Wiper motors

- 53 Wiper motor, input (+)
- 53a Wiper (+), self-parking switch-off
- 53b Wiper (shunt winding)
- 53c Electric windshield-washer pump
- 53e Wiper (brake winding)
- 53l Wiper motor with permanent magnet and third brush (for higher speed)

Lighting

- 55 Fog lamp
- 56 Headlamp
- 56a High beam, high-beam indicator lamp
- 56b Low beam
- 56d Headlamp-flasher contact
- 57a Parking lamp
- 57L Parking lamp, left
- 57R Parking lamp, right
- 58 Side-marker, tail, license plate, and instrument panel lamps
- 58b Dimmer
- 58d Dimmer
- 58L License-plate lamp, left
- 58R License-plate lamp, right

Alternators and voltage regulators

- 61 Alternator charge-indicator lamp
- B+ Battery positive
- B- Battery negative
- D+ Dynamo positive
- D- Dynamo negative
- DF Dynamo field
- DF1 Dynamo field 1
- DF2 Dynamo field 2
- U,V,W Alternator terminals
- 75 Radio, cigarette lighter
- 76 Speakers

Switches**Break contact (NC) and changeover switches**

- 81 Input
- 81a Output 1, NC side
- 81b Output 2, NC side

Make contact (NO) switches

- 82 Input
- 82a Output 1
- 82b Output 2
- 82z Input 1
- 82y Input 2

Multiple-position switches

- 83 Input
- 83a Output, position 1
- 83b Output, position 2
- 83L Output, left-hand position
- 83R Output, right-hand position

Relays/Current relays

84 Input, actuator and relay contact
 84a Output, actuator
 84a Output, relay contact

Switching relays

85 Output, actuator (end of winding to ground or negative)
 86 Input, actuator (start of winding)
 86a Start of winding or 1st winding
 86b Winding tap or 2nd winding

Relay contact for break (NC) and changeover contacts

87 Input
 87a Output 1 (NC side)
 87b Output 2
 87c Output 3
 87z Input 1
 87y Input 2
 87x Input 3

Relay contact for make (NO) contact and changeover contacts

88 Input
 88a Output 1
 88b Output 2
 88c Output 3
 88z Input 1
 88y Input 2
 88x Input 3


Directional signals (turn signal flashers)

C Indicator lamp 1
 C2 Indicator lamp 2
 C0 Main terminal connection for separate indicator circuits actuated by the turn signal switch
 C3 Indicator lamp 3 (e.g., when towing two trailers)
 L Turn-signal lamps, left
 R Turn-signal lamps, right

DIN Standard 72 552 This standard applies to the terminal designations for circuits. The purpose of the terminal designation system is to enable accurate connection identification from conductors (wires) to various components when diagnosis and repair is necessary.

Examples of DIN standards for terminal designations are shown below:

1 Ignition coil primary
 4 Ignition coils secondary
 15 Ignition switched, on and start
 30 Battery
 + 31 Ground
 31b Switched Ground
 50 Starter control
 75/X Load Reduction/Ignition switched on only



1. Relay location number

Indicates location on relay panel. See page 1 of individual wiring diagram for details.

2. Arrow

Indicates wiring circuit is continued on the previous and/or next page.

3. Connector designation - relay/control module on relay panel

Shows relay panel terminals with corresponding relay terminal.
For example: 17/30 equals terminal 30 of relay connects to terminal 17 of central relay panel.

4. Threaded pin on relay panel

White circle shows a threaded removable connection.

5. Fuse designation

For example: S228 equals Fuse 28, 15 amps, in fuse holder.

6. Reference of wire continuation (current track number)

Number in frame indicates current track where wire is continued (see page 3 for example).

7. Wire connection designation in wiring harness

Location of wire connections are indicated in the legend.

8a. Terminal designation on a multipoint connector

8b. Terminal designation on a component
Designation which appears on the actual component and/or terminal number of a multi-point connector.

9. Ground connection designation in wire harness

Locations of ground connections are indicated in legend.

10. Component designation

Use legend at bottom of page to identify the component code.

11. Component symbols

A graphical representation of a component type. See Appendix A, page 35.

12. Wire cross section size (in mm²) and wire colors

Abbreviations are explained in the color chart beside the wiring diagram.

13. Component symbol with open drawing side

Indicated component is continued on another wiring diagram. The number of the corresponding wiring diagram can be found in the table of contents.

14. Internal connections (thin lines)

These connections are not wires. Internal connections are current carrying and are listed to allow tracing of current flow inside components and wiring harness.

a. Internal Harness Splice (Welded Connection)
b. Physical Contact (Mounted to engine)

15. Reference of continuation of wire to component (inset)

For example: Control module for anti-theft immobilizer J362 on 6-pin connector terminal 2.

16. Central Relay panel connectors

Shows wiring of multi-point or single connectors on central relay panel.
For example: S3/3 equals Multi-point connector S3, terminal 3.

17. Reference of internal connection continuation

Letters indicate where connection continues on previous and/or next page.


18. Central Relay Panel

19. Ground Path

ex.: from welded harness connection 135 to welded harness connection 81 to welded harness connection 42.




Battery



Distributor
(electrical)



Thermally
operated
switch




Starter



Spark plug
connector
and plug



Push-button switch
(manually operated)



Generator



Glow plug
heater element



Mechanically
operated
switch




Ignition coil



Manually
operated
switch



Pressure
operated
switch



Multiple switch
(manually operated)



Heater element
(temperature dependent)

SSP 8730/02



Diode



Zener diode



Diode
(light sensitive)



Light bulb



Light bulb
(dual filament)



LED



Interior light



Instrument
(gauge)




Rear window defogger
heat element



Cigarette
lighter



Solenoid valve



Magnetic clutch



Wire connection
in wiring harness




Resistance wire



Shield wire

SSP 8730/03




Control motor,
headlight range
adjustment



Digital clock




Antenna with
electronic antenna
amplifier




Wiper motor
(2-speed)



Multifunction
indicator



Radio




Crankshaft
position sensor




Airbag spiral
spring




Heated oxygen
sensor



Speed sensor



Camshaft
position sensor



Horn




Analog clock



Speaker

T




- A - Battery
- B - Starter
- D - Ignition/Starter Switch
- J59 - Load Reduction Relay
- J226 - Park/Neutral Position (PNP) Relay
- S162 - Fuse -1- (30) in fuse bracket/battery
- S163 - Fuse -2- (30) in fuse bracket/battery
- S164 - Fuse -3- (30) in fuse bracket/battery
- S176 - Fuse -4- (30) in fuse bracket/battery
- S177 - Fuse -5- (30) in fuse bracket/battery
- S178 - Fuse -6- (30) in fuse bracket/battery
- S179 - Fuse -7- (30) in fuse bracket/battery
- S180 - Fuse -8- (30) in fuse bracket/battery
- T3 - 3-Pin Connector
- 2 - Ground strap, transmission to body
- 500 - Threaded connection -1- (30) on the relay plate
- 501 - Threaded connection -2- (30) on the relay plate
- A32 - Plus connection (30), in instrument panel wiring harness
- A41 - Plus connection (50), in instrument panel wiring harness (gasoline engine only)
- A80 - Connector -1- (X) in instrument panel wiring harness
- * - Manual transmission only
- Automatic transmission only

Interior and exterior lighting (NAR)
from April 2011




Terminal 15 power supply relay, Vehicle electrical system control module



Terminal 15 power supply relay 2


- J681 Terminal 15 power supply relay 2
- J935 Converter box
- SC Fuse panel C
- SC6 Fuse 6 (on fuse panel C)
- SC7 Fuse 7 (on fuse panel C)
- SC13 Fuse 13 (on fuse panel C)
- SC15 Fuse 15 (on fuse panel C)
- SC39 Fuse 39 (on fuse panel C)
- T9k 9-pin connector
- T10e 10-pin connector



- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- vi = lilac
- ge = yellow
- or = orange
- rs = pink

Vehicle electrical system control module, Terminal 75 power supply relay 1, Left front fog lamp bulb


- J285 Instrument cluster control module
- J519 Vehicle electrical system control module
- J680 Terminal 75 power supply relay 1
- L22 Left front fog lamp bulb
- SC Fuse panel C
- SC18 Fuse 18 (on fuse panel C)
- SC19 Fuse 19 (on fuse panel C)
- SC31 Fuse 31 (on fuse panel C)
- SC32 Fuse 32 (on fuse panel C)
- SC34 Fuse 34 (on fuse panel C)
- SC55 Fuse 55 (on fuse panel C)
- T9m 9-pin connector
- T32c 32-pin connector
- T73a 73-pin connector
- T73b 73-pin connector



Vehicle electrical system control module, Left daytime running lamp bulb, Right daytime running lamp bulb, Left position lamp bulb, Right position lamp bulb, Left front turn signal bulb, Left low beam headlamp bulb, Left high beam headlamp bulb, Right low beam headlamp bulb, Right high beam headlamp bulb, Left front side marker lamp bulb, Right front side marker lamp bulb

- J519 Vehicle electrical system control module
- L174 Left daytime running lamp bulb
- L175 Right daytime running lamp bulb
- M1 Left position lamp bulb
- M3 Right position lamp bulb
- M5 Left front turn signal bulb
- M29 Left low beam headlamp bulb
- M30 Left high beam headlamp bulb
- M31 Right low beam headlamp bulb
- M32 Right high beam headlamp bulb
- M33 Left front side marker lamp bulb
- M34 Right front side marker lamp bulb
- T10i 10-pin connector
- T10j 10-pin connector
- T73a 73-pin connector
- T73b 73-pin connector

- 376 Ground connection 11 (in main wiring harness)
- 378 Ground connection 13 (in main wiring harness)
- 381 Ground connection 16 (in main wiring harness)
- 655 Ground connection on left headlamp
- A6 Left turn signal positive connection (in instrument panel wiring harness)
- A84 Connection 58L (in instrument panel wiring harness)
- A85 Connection 58R (in instrument panel wiring harness)
- * Only for vehicles with daytime running lamps



Instrument panel and switch illumination dimmer switch,
Vehicle electrical system control module, Right front fog
lamp bulb, Right front turn signal bulb

- E20 Instrument panel and switch illumination dimmer switch
- J519 Vehicle electrical system control module
- J967 Sill panel strip ambient lighting control module
- L23 Right front fog lamp bulb
- L76 Push button illumination bulb
- M7 Right front turn signal bulb
- T8e 8-pin connector
- T16 16-pin connector
- T73b 73-pin connector

378 Ground connection 13 (in main wiring harness)

666 Ground connection on right headlamp

A5 Right turn signal positive connection (in instrument panel wiring harness)

A19 Connection 58d (in instrument panel wiring harness)


A49 Connection 1 (in instrument panel wiring harness)

A138 Connection 2 (in instrument panel wiring harness)

A192 Positive connection 3 (15a) (in instrument panel wiring harness)


- * Depending on equipment
- *2 through July 2011
- *3 from August 2011
- *4 from December 2011
- *5 through December 2011

- WS = white
- SW = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- vi = lilac
- ge = yellow
- or = orange
- rs = pink



Light switch, Fog lamp switch, Vehicle electrical system control module

- E1 Light switch
- E7 Fog lamp switch
- J519 Vehicle electrical system control module
- L9 Headlamp switch illumination bulb
- T3g 3-pin connector
- T17d 17-pin connector
- T73a 73-pin connector
- T73b 73-pin connector
- U1 Cigarette lighter
- 44 Ground connection on A-pillar, lower left
- 86 Ground connection 1 (in rear wiring harness)
- B238 Positive connection 2 (58b) (in interior wiring harness)




Back-up lamp switch, Vehicle electrical system control module, Right tail lamp bulb, Left tail lamp bulb, Left rear turn signal bulb, Right rear turn signal bulb, Left brake lamp bulb, Right brake lamp bulb, Left back-up lamp bulb, Right back-up lamp bulb, High-mounted brake lamp bulb

- F4 Back-up lamp switch
- G66 High pressure sensor
- J519 Vehicle electrical system control module
- M2 Right tail lamp bulb
- M4 Left tail lamp bulb
- M6 Left rear turn signal bulb
- M8 Right rear turn signal bulb
- M9 Left brake lamp bulb
- M10 Right brake lamp bulb
- M16 Left back-up lamp bulb
- M17 Right back-up lamp bulb
- M25 High-mounted brake lamp bulb
- T3c 3-pin connector
- T5n 5-pin connector
- T5o 5-pin connector
- T73b 73-pin connector
- 87 Ground connection 2 (in rear wiring harness)
- 662 Ground connection in left rear side panel
- 663 Ground connection in right rear side panel
- A20 Positive connection 15a (in instrument panel wiring harness)
- A87 Back-up lamp connection (in instrument panel wiring harness)
- A89 Connection 54 (in instrument panel wiring harness) 2
- B182 Connection RF (in interior wiring harness)


* from December 2011
*2 through December 2011

WS = white
SW = black
ro = red
rt = red
br = brown
gn = green
bl = blue
gr = grey
li = lilac
vi = lilac
ge = yellow
or = orange
rs = pink




Emergency flasher button, Brake lamp switch, Luggage compartment lamp switch, Vehicle electrical system control module, Left license plate lamp, Right license plate lamp

- E229 Emergency flasher button
- F Brake lamp switch
- F5 Luggage compartment lamp switch
- G Fuel level sensor
- J104 ABS control module
- J519 Vehicle electrical system control module
- K6 Emergency flasher indicator lamp
- T3a 3-pin connector
- T4f 4-pin connector
- T4y 4-pin connector
- T5b 5-pin connector
- T6bq 6-pin connector
- T47 47-pin connector
- T73a 73-pin connector
- X4 Left license plate lamp
- X5 Right license plate lamp
- 87 Ground connection 2 (in rear wiring harness)
- 195 Ground connection (in rear door contact switch wiring harness)
- 375 Ground connection 10 (in main wiring harness)
- 382 Ground connection 17 (in main wiring harness)
- 383 Ground connection 18 (in main wiring harness)
- 437 Ground connection (in license plate lamp wiring harness)
- 690 Ground connection on roof frame, center rear
- B131 Connection 54 (in interior wiring harness)
- W41 Positive connection (58) (in license plate lamp wiring harness)
- * from December 2011
- *2 through December 2011



Turn signal switch, Headlamp dimmer/flasher switch,
Headlamp dimmer/flasher relay, Vehicle electrical system
control module, Driver exterior rearview mirror turn signal
bulb, Left front door ambient lighting bulb 1




Front passenger exterior rearview mirror turn signal bulb,
Right front door ambient lighting bulb 1, Left front door
ambient lighting bulb 2, Right front door ambient lighting
bulb 2

L132 Front passenger exterior rearview mirror turn signal bulb
L200 Right front door ambient lighting bulb 1
L203 Left front door ambient lighting bulb 2
L204 Right front door ambient lighting bulb 2
T4bd 4-pin connector
T4be 4-pin connector
T4bf 4-pin connector
T10h 10-pin connector
T17b 17-pin connector
T17c 17-pin connector

205 Ground connection (in driver door wiring harness)
206 Ground connection (in front passenger door wiring harness)
R94 Connection 1 (in driver door wiring harness)
R95 Connection 2 (in driver door wiring harness)
R96 Connection 3 (in driver door wiring harness)
R98 Connection 1 (in front passenger door wiring harness)
R99 Connection 2 (in front passenger door wiring harness)
R100 Connection 3 (in front passenger door wiring harness)

through July 2011
Depending on equipment
from August 2011




Vehicle electrical system control module, Front interior lamp, Luggage compartment lamp, Front passenger vanity mirror lamp, Driver vanity mirror lamp, Left center reading lamp, Right center reading lamp


- E508 Cellular telephone preparation control head
- F147 Driver vanity mirror lamp contact switch
- F148 Front passenger vanity mirror lamp contact switch
- J519 Vehicle electrical system control module
- J682 Terminal 50 power supply relay
- T2bs 2-pin connector
- T2bt 2-pin connector
- T2bu 2-pin connector
- T2bv 2-pin connector
- T6av 6-pin connector
- T6b 6-pin connector
- T9b 9-pin connector
- T73a 73-pin connector
- W1 Front interior lamp
- W3 Luggage compartment lamp
- W14 Front passenger vanity mirror lamp
- W20 Driver vanity mirror lamp
- W39 Left center reading lamp
- W40 Right center reading lamp

- 402 Interior lighting ground connection (in interior wiring harness)
- 459 Ground connection 15 (in interior wiring harness)
- B150 Positive connection 2 (30a) (in interior wiring harness)
- B154 Connection TK (in interior wiring harness) 1

* through December 2011
*2 from December 2011



1 - Fuse panel C -SC-



Fuse location	Designation in Wiring Diagram	Nominal Value	Function/Component	Terminal
F1	Not used	-		-
F2	Not used	-		-
F3	Fuse 3 (on fuse panel C) -SC3-	5 A	Instrument cluster control module -J285- (T32c/32)	30a
F4	Fuse 4 (on fuse panel C) -SC4-	5 A	Telephone Transceiver -R36- (T54/1)	30a
			Instrument cluster control module -J285- (T32c/13)	

Fuse location	Designation in Wiring Diagram	Nominal Value	Function/Component	Terminal
F5	Fuse 5 (on fuse panel C) -SC5-	10 A	Vehicle electrical system control module -J519- (T73a/6) Left rear fog lamp bulb -L46- (2)	55a
F6	Fuse 6 (on fuse panel C) -SC6-	10 A	Release button in rear lid handle -E234- (4) Rearview camera -R189- (T4ak/1)	30a
F7	Fuse 7 (on fuse panel C) -SC7-	5 A	Instrument panel and switch illumination dimmer switch -E20- (T8e/3) Left license plate lamp -X4- (2) Right License Plate Light -X5- (2)	58
F8	Fuse 8 (on fuse panel C) -SC8-	7.5 A	Windshield washer pump -V5- (1)	53c
F9	Fuse 9 (on fuse panel C) -SC9-	5 A	Airbag control module -J234- (T75/1), (T75/2/6), (T50/1), (T50/2/6) Front passenger airbag -disabled- indicator lamp -K145- (T4g/3)	15a
F10	Fuse 10 (on fuse panel C) -SC10-	10 A	Windshield wiper intermittent mode switch -E22- (T10m/3)	15a
F11	Not used	-		-
F12	Fuse 12 (on fuse panel C) -SC12-	5 A	Headlamp range control module -J431- (T26c/23) Stop/Start system main switch -E101- (T6bx/4), (T6bx/2) Mirror folding switch -E263- (T10o/5) Tire pressure monitoring display button -E492- (T6am/4) Back-up lamp switch -F4- (1) High pressure sensor -G65- (T3c/3) Air quality sensor -G238- (T3an/1) Heater Control Module -J162- (T20c/19) Parking aid control module -J446- (T16m/1) Vehicle positioning system control module -J895- (T16n/1) Automatic dimming interior rearview mirror -Y7- (T6am/1) Left washer nozzle heater -Z20- (1) Right washer nozzle heater -Z21- (1)	15a
F13	Fuse 13 (on fuse panel C) -SC13-	5 A	Turn signal switch -E2- (T16j/1) tiptronic switch -F189- (T10s/9) Oil level thermal sensor -G266- (1) -GX22- (T10ak/3) ABS control module -J104- (T47/8) Instrument cluster control module -J285- (T32c/31) Power steering control module -J500- (T3ao/3) Steering column electronics control module -J527- (T16p/14)	15a
F14	Fuse 14 (on fuse panel C) -SC14-	10 A		

Fuse location	Designation in Wiring Diagram	Nominal Value	Function/Component	Terminal
			Voltage stabilizer -J532- (T12z/3) Data bus on board diagnostic interface -J533- (T20/14) Fuel pump control module -J538- (T10v/3) Selector lever sensor system control module -J587- (T10s/9) Engine control module -J623- (T91/50) 27 Positive crankcase ventilation heating element -N79- (1)21	
F15	Fuse 15 (on fuse panel C) -SC15-	5 A	Instrument panel and switch illumination dimmer switch -E20- (T8e/1) Mass airflow sensor -G70- (T5d/3) 13 (T5d/5) 4 (T3ar/2) 7 Engine sound generator control module -J943- (T12p/1) 29 Left headlamp beam adjustment motor -V48- (T10i/1) Right headlamp beam adjustment motor -V49- (T10j/1) 16-pin connector -T16- (T16/1), data link connector	15a
F16	Fuse 16 (on fuse panel C) -SC16-	5 A	Engine control module -J623- (T94/87)	15a
F17	Fuse 17 (on fuse panel C) -SC17-	10 A	Interior monitoring sensor -G273- (T4bz/4) Alarm horn -H12- (T3f/3)	30a
F18	Fuse 18 (on fuse panel C) -SC18-	15 A	Left low beam headlamp bulb -M29- 1)	56bl
F19	Fuse 19 (on fuse panel C) -SC19-	15 A	Right low beam headlamp bulb -M31- 1) tiptronic switch -F189- (T10s/10) Heater Control Module -J162- (T20c/18)	56br
F20	Fuse 20 (on fuse panel C) -SC20-	5 A	Automatic transmission control module -J217- (T52/3) Climatronic control module -J255- (T20c/20) A/C control module -J301- (T20c/19) Selector lever sensor system control module -J587- (T10s/10) Ignition switch key lock solenoid -N376- (T10d/10)	30a
F21	Fuse 21 (on fuse panel C) -SC21-	15 A	Vehicle electrical system control module -J519- (T73b/68)	30a
F22	Fuse 22 (on fuse panel C) -SC22-	5 A	Ignition/starter switch -D- (T10d/1) Vehicle positioning system control module -J895- (T16n/2) Converter box -J935- (T10e/7)	30a
F23	Fuse 23 (on fuse panel C) -SC23-	20 A	Rain/light recognition sensor -G397- (T3ae/1) Vehicle electrical system control module -J519- (T73b/39), (T73a/66) Telephone Transceiver -R36- (T54/1) 16-pin connector -T16- (T16/16), data link connector -GX22- (T10ak/1)	30a



Fuse location	Designation in Wiring Diagram	Nominal Value	Function/Component	Terminal
F24	Fuse 24 (on fuse panel C) -SC24-	10 A	Vehicle electrical system control module -J519- (T73a/64) Access/start authorization control module -J518- (T32d/3) Electronic steering column lock control module -J764- (T16s/2) Data bus on board diagnostic interface -J533- (T20/1)	30a
F25	Fuse 25 (on fuse panel C) -SC25-	25 A ³²⁾ 10 A	Multifunction transmission range switch -F125- (T10n/10) Automatic transmission control module -J217- (T52/27) ³²⁾ (T52/28) ³²⁾ DSG transmission Mechatronic -J743- (T25/10) ³⁰⁾ (T20/13) ³¹⁾	15a
F26	Not used	-		-
F27	Not used	-		-
F28	Not used	-		-
F29	Fuse 29 (on fuse panel C) -SC29-	5 A	Vehicle electrical system control module -J519- (T73b/51)	75
F30	Fuse 30 (on fuse panel C) -SC30-	20 A	Blocking diode -J29- (1) Cigarette lighter -U1- (T3g/2) 12 V socket -J5- (2)	75a
F31	Fuse 31 (on fuse panel C) -SC31-	30 A	Light switch -E1- (T17d/1)	75
F32	Fuse 32 (on fuse panel C) -SC32-	15 A	Fog lamp switch -E7- (T17d/2)	75a
F33	Fuse 33 (on fuse panel C) -SC33-	40 A	Heater Control Module -J162- (T5/5) A/C control module -J301- (T5/5)	75a
F34	Fuse 34 (on fuse panel C) -SC34-	10 A ³⁴⁾ 15 A ³⁵⁾	Instrument cluster control module -J285- (T32c/14) Vehicle electrical system control module -J519- (T73a/62) Left high beam headlamp bulb -M30- (T10i/8) Right high beam headlamp bulb -M32- (T10j/8) Left front headlamp -MX1- (T14c/11) Right front headlamp -MX2- (T14c/11)	56al
F35	Fuse 35 (on fuse panel C) -SC35-	1 A	Steering column electronics control module -J527- (T16p/1)	15a
F36	Fuse 36 (on fuse panel C) -SC36-	30 A	Vehicle electrical system control module -J519- (T73a/16)	30a
F37	Fuse 37 (on fuse panel C) -SC37-	5 A	Left daytime running lamp bulb -L174- (T10i/4)	DRL
F38	Fuse 38 (on fuse panel C) -SC38-	5 A	Right daytime running lamp bulb -L175- (T10j/4)	DRL
F39	Fuse 39 (on fuse panel C) -SC39-	30 A	Headlamp dimmer/flasher relay -J- (T9a/3)	30
F40	Not used	-		-
F41	Not used	-		-
F42	Not used	-		-

Fuse location	Designation in Wiring Diagram	Nominal Value	Function/Component	Terminal
F43	Fuse 43 (on fuse panel C) -SC43-	30 A	Front passenger door control module -J387- (T16d/16)	30a
F44	Fuse 44 (on fuse panel C) -SC44-	30 A	Vehicle electrical system control module -J519- (T73b/67)	30a
F45	Fuse 45 (on fuse panel C) -SC45-	30 A	Driver door control module -J386- (T16c/16)	30a
F46	Not used	-		-
F47	Fuse 47 (on fuse panel C) -SC47-	20 A	Fuel Pump (FP) Relay -J17- (3A) Electric fuel pump relay 2 -J49- (3B) ¹⁷⁾ Fuel pump control module -J538- (T10v/1)	30a
F48	Fuse 48 (on fuse panel C) -SC48-	30 A	Vehicle electrical system control module -J519- (T73b/13), (T73b/11)	30a
F49	Fuse 49 (on fuse panel C) -SC49-	40 A	Fresh Air Blower Control Module -J126- (T6l/4)	30a
F50	Fuse 50 (on fuse panel C) -SC50-	30 A	Front seat heating control module -J774- (T8v/3), (T8v/6)	30a
F51	Fuse 51 (on fuse panel C) -SC51-	30 A	Sunroof control module -J245- (T10f/10)	30a
F52	Fuse 52 (on fuse panel C) -SC52-	20 A	Vehicle electrical system control module -J519- (T73a/63)	30a
F53	Fuse 53 (on fuse panel C) -SC53-	20 A	Vehicle electrical system control module -J519- (T73a/73)	30a
F54	Not used	-		-
F55	Fuse 55 (on fuse panel C) -SC55-	20 A	Light switch -E1- (T17d/15) Headlamp dimmer/flasher switch -E4- (T16/10)	30
F56	Not used	-		-
F57	Fuse 57 (on fuse panel C) -SC57-	25 A	Radio/navigation display unit control module -J503- (T16b/15), (T16b/16) Radio -R- (T16b/15), (T16b/16)	30a
F58	Not used	-		-
F59	Not used	-		-
F60	Not used	-		-

¹⁾Not for models with DSG transmission

⁴⁾Engine code CJAA

⁷⁾Engine code CAYC

¹³⁾Engine codes CBFA, CCTA, CCZA

¹⁷⁾Engine codes CFFB, CJAA

²¹⁾Engine code CFFB

²⁷⁾Engine codes CPLA, CPLB, CPPA

³⁰⁾For vehicles with DSG transmission 02E



The Beetle


Component Locations

No. 895 / 4

1.6.1 73-pin (a)

Black connector

73-pin connector -T73a-



Cavity	Function	Cavity	Function
1	...	38	Connection (mirror adjustment/heating), in dash panel wiring harness
2	Left headlight dipped beam bulb -M29-, Front left headlight -MX1-	39	...
3	...	40	Connection (58R), in dash panel wiring harness
4	Connection 1 (DCT), in interior wiring harness	41	Connection (58L), in dash panel wiring harness
5	Right LED module for daytime running light and side light -L177-, Front right headlight -MX2-	42	Electronic ignition lock -D9-, Control unit for electronic steering column lock -J764-
6	Connection (rear fog light), in main wiring harness	43	Connection (54), in interior light wiring harness
7	Rear fog light switch -E18-	44	Supply input signal (15) for ignition/starter switch
8	...	45	Light switch -E1-
9	...	46	...
10	Rear lid release motor output signal	47	Entry and start authorisation control unit -J518-
11	Central locking motor "lock" output signal for all doors	48	...
12	Connection 2 (central locking), in interior wiring harness	49	...
13	Central locking motor "Safe" output signal for all doors	50	...
14	Terminal 31	51	...
15	Connection 3 (central locking), in interior wiring harness, Driver door central locking motor -V56-	52	Fuel supply relay output signal
16	Terminal 30	53	Alarm horn relay -J641-
17	...	54	Terminal 75 voltage supply relay 1 -J680- 1), Positive connection (75a) in dash panel wiring harness 2)
18	...	55	Converter box -J935-
19	Driver side central locking lock unit -F220-	56	Hazard warning lights button -E229-

Cavity	Function	Cavity	Function
20	Front passenger side central locking lock unit -F221-	57	Deactivation button for vehicle inclination sender -E360-
21	Front passenger side central locking lock unit -F221-	58	Central locking SAFELock function warning lamp -K133-
22	Driver door central locking motor -V56-	59	Connection 2 (central locking), in main wiring harness
23	Rear lid handle release button input signal	60	Air conditioning system control unit -J301- 3), Heater control unit -J162- 4)
24	Driver side central locking lock unit -F220-	61	...
25	Connection 1 (central locking), in main wiring harness, Driver side interior locking button for central locking system -E308-	62	Positive connection 1 (56a), in interior wiring harness
26	...	63	Terminal 30
27	Hood contact switch -F266-	64	Positive connection (30a), in dash panel wiring harness
28	Hazard warning lights button -E229- Front passenger side central locking lock unit -F221- 1)	65	Positive connection 2 (30a), in interior wiring harness
29	Horn plate input signal	66	Positive connection 3 (30a) in dash panel wiring harness
30	Ground connection, in rear door switch wiring harness	67	...
31	Rear lid electric opener motor -V254-	68	Terminal 30
32	Right turn signal switch input signal	69	Wiper motor control unit -J400-
33	Left turn signal switch input signal	70	Terminal 31
34	...	71	Wiper motor control unit -J400-
35	...	72	Connection (dual tone horn), in dash panel wiring harness
36	Heated front seats control unit -J774-	73	Terminal 30
37	...		

1) To December 2012

2) From December 2012

3) To June 2012


4) From June 2012



1.6.2 73-pin (b)

White connector

73-pin connector - T73b-



Cavity	Function	Cavity	Function
1	Switch and instrument illumination regulator -E20-	38	Terminal 31
2	Right headlight dipped beam bulb -M31-, Front right headlight -MX2-	39	Supply input signal (30) for electronics
3	Left LED module for daytime running light and side light -L176-, Front left headlight -MX1	40	...
4	...	41	...
5	Front left headlight -MX1-	42	...
6	Front right headlight -MX2-	43	Fog light switch -E7-
7	Positive connection 2 (58), in dash panel wiring harness, Positive connection (58), in number plate lights wiring harness ²⁾	44	Turn signal switch -E2-
8	...	45	Connection (CCS), in dash panel wiring harness
9	Left fog light bulb -L22-	46	Turn signal switch -E2-
10	Right fog light bulb -L23-	47	Turn signal switch -E2-
11	Terminal 30 (fog light)	48	Connection (RL), in interior wiring harness
12	Connection (RL), in dash panel wiring harness	49	Connection (61), in dash panel wiring harness
13	Terminal 30 (turn signal, brake lamp)	50	Positive connection (50), in dash panel wiring harness
14	Connection (left turn signal), in headlight wiring harness	51	Connection (75a), in dash panel wiring harness
15	Connection 2 (right turn signal), in headlight wiring harness	52	Light switch -E1-
16	Connection 2 (54) in dash panel wiring harness	53	Intermittent wiper switch -E22-
17	Connection 1 (LIN bus) in main wiring harness	54	...
18	Connection 1 (powertrain CAN bus, low), in main wiring harness	55	Clutch position sender -G476-, Mechatronic unit for dual clutch gearbox -J743-
19	Connection 1 (powertrain CAN bus, high), in main wiring harness	56	...



Component Locations

Cavity	Function	Cavity	Function
20	Connection 1 (convenience CAN bus, high), in main wiring harness	57	...
21	Connection 1 (convenience CAN bus, low), in main wiring harness	58	Exterior mirror heater button -E231-
22	Diagnostic connection -U31	59	Terminal 30
23	Diagnostic connection -U31	60	Terminal 31
24	Connection 2 (LIN bus) in main wiring harness	61	Connection (53c), in dash panel wiring harness
25	...	62	Intermittent wiper switch -E22-
26	...	63	Frequency modulation (FM) frequency filter in positive wire -R179- I
27	Window wiper position 1 input signal	64	...
28	...	65	...
29	Light switch -E1-	66	...
30	Interior monitoring deactivation switch input signal	67	Heated rear window supply input signal (30)
31	Air conditioning system control unit -J301- 3), Heater control unit -J162- 4)	68	Supply input signal (30), right headlight
32	Wiper motor control unit -J400-	69	...
33	...	70	...
34	Positive connection 2 (58b), in interior wiring harness	71	...
35	...	72	...
36	Alarm horn -H12-	73	...
37	Connection 1 (LIN bus) in dash panel wiring harness 2)		

1) To December 2012

2) From December 2012

3) To June 2012

4) From June 2012

Minimum Software / Hardware Requirements 2GB of RAM CPU better than Pentium 4 @ 2GHZ 80GB of free hard drive 15" Monitor with 1024 x 768 resolution Microsoft Windows 7 Professional 64 bit or Microsoft Windows 7 Enterprise 64 bit with SP1

Connectivity Requirements Local Area Network internet connection with a minimum of 2Mbit per second download / upload speed. Mozilla Firefox 4 or higher Microsoft Internet Explorer 7 or later as least 1 free USB port Network connection to the internet with no proxy connections Pass - Through Tool (PTT) that is SAE-J2534 compatible

What is J2534 and Pass-Thru Programming?

J2534, also known as Pass Through, ensures that independent repair shops can work on modern cars and have cost-effective access to information and ECU programming downloads from vehicle manufacturer when required.

SAE J2534 is a communications standard adopted by vehicle manufacturers that enables compliant devices to reprogram vehicle ECUs. US legislation requires vehicle manufacturers to make vehicles, diagnostic and reprogramming applications that are compatible with J2534 devices, such as the Drew Technologies CarDAQ-Plus 2 (only available in North America) interface.

Most modern cars can now be reprogrammed using the J2534 standard. Our products and services enable this without the need for separate, expensive OE tools for each brand.

How to Apply to Become a "Registered" Vehicle Security Professional through the NASTF Registry the NASTF Vehicle Security Professional "Registry" The NASTF "Registry" is the foundation of the Secure Data Release Model; it is the repository of secure, background checked Vehicle Security Professionals (VSP). A VSP is an automotive locksmith or repair technician who specializes in services that require use of security-related service information. These services include immobilizer resets, component replacements that require initialization of security systems and creation/registration of high security keys. Locksmiths and auto repair technicians who have a need to access automaker security-related service information can apply for inclusion in the Registry.

The NASTF “Registry” process requires completion of a comprehensive application and submission to the NASTF Registry Administrator. The Registry is administered by the Automotive Service Association (ASA). Trade association membership is not required to be included in the Registry. Applicants to the Registry agree to undergo a background check and abide by the Registry Terms & Conditions of Use.

Details can be found on the NASTF Registry website at <http://nastf.org/i4a/pages/index.cfm?pageid=3532>. Once accepted into the Registry, the VSP is issued a security credential known as an LSID or Locksmith Identification number.

With a valid LSID, a VSP has access to security related information from participating automaker service information websites and/or call centers. A valid LSID and password is issued by the Registry for each individual authorized to access automaker security-related information.

The LSID and password is required for every service information transaction that involves security-related data. What is the NASTF Vehicle Security Registry - How to Apply v 11-21-11 The Application Process: To apply for inclusion in the “Registry” a VSP must: • Obtain a Registry Application & User Agreement from the Registry website or SDRM Director of Operations (SDRM@nastf.org)

- Carefully read the User Agreement (an integral part of the application) and the Terms & Conditions of Use.
- Complete the application in its entirety, including SSN, Fed Tax ID and professional license information (where applicable).
- Provide proof of required insurance and bonding (details are in the application).
- Sign the completed application in the presence of an authorized notary public to notarize the application.
- Mail, Email or FAX the notarized application form and all required supporting documentation to the NASTF Registry Director of Operations at the address on the application (be sure to make and retain photo copies of the entire application package).
- Within fourteen (14) days of receipt by the NASTF, a criminal background check will be performed and you will be notified by e-mail of your application status.
- (NOTE: applications without a permanent business address, proof of legitimate business operations, SSN, Federal Tax ID, Driver's License issued by the state in which the applicant is doing business will not be considered)
- Acceptance into the registry will result in issuance of a Locksmith Identification number (LSID) and temporary password via your account email address. Instructions on managing your password and other account information will be included in the welcome email and are available on the NASTF Registry website with general instructions on use of the Registry Administrative Website.
- If rejected, the applicant has the right to appeal within thirty (30) calendar days to the NASTF Security Review Committee. IMPORTANT: YOUR LSID IS ASSOCIATED WITH YOUR NAME, YOUR SOCIAL SECURITY NUMBER AND YOUR BUSINESS IDENTIFICATION. TRANSACTIONS FOR SECURITY-RELATED INFORMATION

ARE LOGGED BY THE NATIONAL INSURANCE CRIME BUREAU AND MONITORED BY THE NATIONAL CRIME INFORMATION CENTER. MISUSE OF YOUR LSID IS DIRECTLY TRACEABLE BACK TO YOU. INAPPROPRIATE USE OF LSID: IT IS A VIOLATION OF THE REGISTRY TERMS & CONDITIONS OF USE TO SHARE YOUR LSID CREDENTIAL WITH ANYONE. IT IS ALSO A VIOLATION TO SHARE INFORMATION ACQUIRED WITH YOUR LSID WITH OTHERS. VIOLATION OF THE REGISTRY TERMS & CONDITIONS OF USE WILL RESULT IN SUSPENSION OR REVOCATION OF YOUR LSID

What OEM equipment is available to reprogram vehicles?

- I+ME Pass-Thru+XS Available from ACTIA Corp www.actiaus.com or (734) 266-2083
- DrewTech CarDAQ Plus, CarDAQ M, or Mongoose Pro VW Available from Drew Technologies, Inc. <http://www.drewtech.com> or (734) 222-5228
- Blue Streak iflash Global Programmer Available from Blue Streak Electronics, <http://www.bsecorp.com> or (905) 669-4812
- DG Technologies VSI-2534 Available from DG Technologies www.dgtech.com or (248) 888-2000


VW/AUDI

Subscribing to IDOS and PASS-THRU device

<https://erwin.audiusa.com>

erWin Portal


- Home
- About erWin
- Search
- Vehicle Diagnostics
- Reprogramming
- Security Professionals Key Program
- My erWin



Welcome to erWin

Home

Audi
Truth in Engineering



Login

User Name

Password

Log In

Password Forgotten

Info

Not logged in

erWin Portal

- Home
- About erWin
- Search
- Vehicle Diagnostics
- Reprogramming
- Security Professionals Key Program
- My erWin

Registration

User Name *	<input type="text"/>
Email *	<input type="text"/>
First Name *	<input type="text"/>
Last Name *	<input type="text"/>
Title	<input type="text"/>
Customer Type	<input checked="" type="radio"/> Business <input type="radio"/> Personal
Business	<input type="text"/>
Telephone	<input type="text"/>
Address *	<input type="text"/>
City *	<input type="text"/>

Login

erWin Portal

[Home](#) [About erWin](#) [Search](#) [Vehicle Diagnostics](#) [Reprogramming](#) [Security Professionals Key Program](#) [My erWin](#)



Welcome to erWin

Home

Truth in Engineering 

Login

User Name:

Password:

Log In

[Password Forgotten](#)

Info

Not logged in

Registration



This will bring you to the screen seen on the next page

erWin Portal

[Home](#) [About erWin](#) [Search](#) [Vehicle Diagnostics](#) [Reprogramming](#) [Security Professionals Key Program](#) [My erWin](#)

*** Steps 1 through 5 must be completed in order!**

You must fulfill the following requirements:

Hardware for the connection with the VAS tester:
VAS 6150A, B or C; VAS5054A
VAS 6160, 6160A; VAS 5054A

Introduction to ODIS Service, please read the following documents before proceeding

- Introduction Guide
- ODIS-Service - Installation Instructions for Independent Repair Facilities
- VAS Diagnostic Devices - Windows® 7 Installation Instructions for Independent Repair Facilities
- ODIS FAQs

Perform only those steps not already completed.

- | | |
|--------|---|
| Step 1 | ➤ Independent Shop Registration
Required to obtain Site ID. Allow one to two weeks processing. (If you are already registered and know your site ID, proceed to Step 2.) |
| Step 2 | ➤ Order Diagnostic Software DVD
Only one DVD is required for both Audi and VW applications. |
| Step 3 | ➤ Request Security Certificate
Required to obtain Org ID, Global user ID, password and certificate. |
| Step 4 | ➤ Obtain Diagnostic License
Required to activate diagnostic software. |
| Step 5 | ➤ Purchase Diagnostic Subscription
A subscription provides one year of unlimited access to all ODIS System diagnostic and reprogramming functions. |

Perform only those steps not already completed.

- | | |
|--------|---|
| Step 1 | > Independent Shop Registration
Required to obtain Site ID. Allow one to two weeks processing. (If you are already registered and know your site ID, proceed to Step 2.) |
| Step 2 | > Order Diagnostic Software DVD
Only one DVD is required for both Audi and VW applications. |
| Step 3 | > Request Security Certificate
Required to obtain Org ID, Global user ID, password and certificate. |
| Step 4 | > Obtain Diagnostic License
Required to activate diagnostic software. |
| Step 5 | > Purchase Diagnostic Subscription
A subscription provides one year of unlimited access to all ODIS System diagnostic and reprogramming functions. |

Click link and download registration form, fill out and submit to email provide in form

[Home](#) | [About erWin](#) | [Search](#) | [Vehicle Diagnostics](#) | [Reprogramming](#) | [Security Professionals Key Program](#) | [My erWin](#)

erWin Online

In order to gain access to various on-line systems needed for diagnostic work and security related functions, registration is required.
If you are not a registered shop, please download, complete and fax or email per the instructions on the form.

[Download Registration Form](#)

[To the Vehicle Diagnostics start page](#)

Login

Logged in as
vag

[Log Out](#)

[Change password](#)

Info

Logged in as:
vag

Your subscription expires in:
209 days 3 hrs, 45 mins.

NOTE:

Register for Audi form. It does both Audi and Volkswagen.

There is a fee of 100 U.S dollars

And you must include copy of you're:

- ***Business license or Local Jurisdiction***
- ***Locksmith license or Local Jurisdiction***
- ***Application fee***
- ***Business card or Letterhead with Business Name***

Go to step 2. Download file

and submit once all entries are filled

In order to receive on line software updates to the Offboard Diagnostic Information System, you also need an Offboard Diagnostic Information System security certificate. Please follow the following steps:

1. Your Site ID was assigned as part of your registration. If you do not know your site ID, please request it from techinfo@vw.com
2. If you do not have a Hardware ID please download and run the " > Hardware ID generator" on your tester.
3. When you receive your Security Certificate via e-mail, please save it to your VAS desktop and USB drive as it will be required later during your ODIS installation.

Site ID *	<input type="text"/>
Contact Name *	<input type="text"/>
Phone number *	<input type="text"/>
Email Address *	<input type="text"/>
Hardware-ID *	<input type="text"/>
Make *	<input type="radio"/> Audi <input type="radio"/> Lamborghini

[> Request Security Certificate](#)

Go to step 3

* Steps 1 through 5 must be completed in order!

You must fulfill the following requirements:

Hardware for the connection with the VAS tester:
VAS 6150A, B or C: VAS5054A
VAS 6160, 6160A: VAS 5054A

Introduction to ODIS Service, please read the following documents before proceeding

- > Introduction Guide
- > ODIS-Service - Installation Instructions for Independent Repair Facilities
- > VAS Diagnostic Devices - Windows® 7 Installation Instructions for Independent Repair Facilities
- > ODIS FAQs

Perform only those steps not already completed.

- | | |
|--------|---|
| Step 1 | > Independent Shop Registration
Required to obtain Site ID. Allow one to two weeks processing. (If you are already registered and know your site ID, proceed to Step 2.) |
| Step 2 | > Order Diagnostic Software DVD
Only one DVD is required for both Audi and VW applications. |
| Step 3 | > Request Security Certificate
Required to obtain Org ID, Global user ID, password and certificate. |
| Step 4 | > Obtain Diagnostic License
Required to activate diagnostic software. |
| Step 5 | > Purchase Diagnostic Subscription
A subscription provides one year of unlimited access to all ODIS System diagnostic and reprogramming functions. |

Go to step 4



erWin Online

In order to receive on line software updates to the Offboard Diagnostic Information System, you also need an Offboard Diagnostic Information System security certificate. Please follow the following steps:

1. Your Site ID was assigned as part of your registration. If you do not know your site ID, please request it from techninfo@vw.com
2. If you do not have a Hardware ID please download and run the "[Hardware ID generator](#)" on your tester.
3. When you receive your Security Certificate via e-mail, please save it to your VAS desktop and USB drive as it will be required later during your ODIS installation.

Site ID *
Contact Name *
Phone number *
Email Address *
Hardware-ID *

[Request Security Certificate](#)

[To the Vehicle Diagnostics start page](#)

Login

Logged in as
vag

[Log Out](#)

[Change password](#)

Info

Logged in as:
vag

Your subscription expires in:
209 days 3 hrs. 2 mins.

Go to step 5

*** Steps 1 through 4 must be completed BEFORE purchasing the ODS Service subscriptions!**

You have access to perform these tasks under the Offboard Diagnostic Information System:

- Vehicle diagnostics
- Security-relevant tasks
- On-line diagnostic software updates

Access to tasks performed under the Offboard Diagnostic Information System incurs a fee and must be booked for fixed periods of time (subscriptions). During access you can perform diagnostic tasks on vehicles through the Offboard Diagnostic Information System. Use the same ORG ID you received with your certificate to order both Audi and VW Subscriptions. Order the VW subscription on the VW Erwin site. Order the Audi Subscription on the Audi Erwin site.

Access to... * ☒ ODIS Flatrate (Y) (\$750.00)

Org-ID *

Make * ☒ Audi ☐ Lamborghini

[Purchase Subscription](#)

Service Information

Offboard Diagnostic Information System Service (ODIS Service)

Subject: ODIS Service Installation

Date: Oct. 25, 2017

1.0 – Introduction

1.1 – General Information

This document describes the **download, installation and configuration** of **ODIS Service diagnostic software** on diagnostic laptop and tablet devices. These instructions apply to initial installations on new devices, i.e.: ODIS Service not previously installed, and reinstallation on existing devices, i.e.: where the Windows system was recovered.

Some instructions differ slightly between Windows 7 and Windows 10 devices.

1.2 – Preparation Overview

- Steps 1, 2 and 3 have been completed on **erWin > Vehicle Diagnostics**
- If you use a J2534 PassThru Diagnostic Device, **please ensure the software is installed prior** to installing ODIS.
- **Disable All Anti-Virus Software**

2.0 – Installation

2.1 – Download & Install Application Data – “Single Setup”

Notes:

- *The following steps illustrate the Single Setup process on device with **Windows 10**.*
- *The process screens on a device with **Windows 7** are similar.*

1. **Open Internet Explorer**
2. Carefully enter the VWAG Group Services web-server URL into the browser's address bar exactly as illustrated below, and then click the “Go to” arrow:




Service Information

Note: If you're unable to reach the web-server URL, try both options below before contacting Diagnostic Software Support for assistance.

1. Go to Tools > Internet Options > Advanced and scroll to the bottom. Of all the SSL and TLS options, ensure **ONLY TLS 1.0 and SSL 3.0** are checked, then **re-try the URL**.
2. Go to Tools > Internet Options > Advanced and near the bottom of this Window, click Reset. **This action requires you to re-start Windows, then re-try the URL.**
3. Go to Tools > Internet Options > Content > Certificates and ensure the VWGoA ODIS RootCA certificate is not expired.

If you do NOT receive the Confirm Certificate prompt shown below, then you may be typing the address incorrectly or you did not install the ODIS Certificate. For ODIS Certificate Installations, refer to the email you received from VWGoA Dealer Fax with your certificate. It contains the instructions for installing the certificate.

3. Select **OK**:



Note:

If multiple certificate confirmation prompts appear, select and confirm the one indicated as:

Issuer: VWGoA ODIS RootCA

4. Navigate through the **web-server Indexes** in the following order:

➤ **Odís/Trade-Retail/software/installation/**

5. From the Index list, double-click the **latest ODIS Service installation version .exe** (listed by date):

Index of /dav/Odis/Trade-Retail/software/installation				
	OffboardDiagSetup-Service VWMCD 3 1 0-RC384P P3 B32 3 8 1.exe	21-Jun-2016	22:02	630M
	OffboardDiagSetup-Service VWMCD 3 1 1-RC387P B32 6 1 6.exe	23-Aug-2016	22:02	627M
	OffboardDiagSetup-Service VWMCD 3 1 2-B32 7 2 10.exe	20-Sep-2016	22:25	649M
	OffboardDiagSetup-Service VWMCD 3 1 3-B32 8 2 1.exe	08-Nov-2016	22:08	631M
	OffboardDiagSetup-Service VWMCD 4 0 0-B40 X X .exe	07-Feb-2017	XX:XX	XXXM

Service Information


Note:

The installation version illustrated here is an example only! Versions are updated regularly. Always download the latest version by date!


6. Click **Save**. The file will be saved in your Downloads Folder.



7. Once the download is complete, click **View downloads**.




8. Locate the OffboardDiagSetup.exe file in the Downloads folder, **right click it and choose Run as administrator**.



9. When the download is complete, **Close** the browser session.

10. No action needed:



Service Information


Note:

The installation version illustrated here is an example only! Versions are updated regularly. Always download the latest version by date!


6. Click **Save**. The file will be saved in your **Downloads Folder**.



7. Once the download is complete, click **View downloads**.




8. Locate the OffboardDiagSetup.exe file in the Downloads folder, **right click it and choose Run as administrator**.




9. When the download is complete, **Close** the browser session.

10. No action needed:



Service Information


11. Confirm **English (US)** is selected, click OK





Notes:

- **English is the default language selection. If this is a Lamborghini or Bentley installation select English (GB)**

12. Next




Select **Next . . . Next:**




Service Information

13. Click the **Target platform dropdown selection arrow**, select the **diagnostic device model number or type** that applies to the device, and then select **Next**:




14. Click the **Diagnostic interface dropdown arrow**, and then select the applicable diagnostic interface: **Either** PassThru, **VAS5054**, **OR VAS6154** (ref. **Note:** below), and then select **Next**:




Service Information

15. **Windows 7 with PassThru or VAS5054A:** Select **Next** to confirm the **device connection**.

16. **Windows 7 and 10 with VAS 6154:** Select **Next**: (Entering a hostname is optional.)




17. Ensure **Copy license to the license folder** is checked, and then click **Search...**:



18. **Browse to the license.dat location.** This is the license you requested on **erWin > Vehicle Diagnostics > Step 3**.

19. **Select / highlight** the license (.dat) file (**DO NOT double-click**), and then click **Open**:




Note:


DO NOT double-click the license file (to open it) in its saved locations!

Service Information


20. Ensure the **license file directory path** appears in the **installation window**, and then select **Next**:



21. No action needed. Select **Next**:




22. **Wait** while several different phases of the installation take place:




Service Information


23. Select **Install**:



24. Click **Finish**:



25. Select **Yes**:



Service Information

2.1.1 - Verify Diagnostic Interface Installed Correctly

1. If you selected the VAS 5054 during the ODIS installation, please confirm the following 2 applications open. If not, please un-install and re-install ODIS.

Click the Windows Button > All Programs > Softing D-PDU API for VCI's

- Click EDIC Configuration Manager
- Click EDIC Hardware Installation

2. If you selected VAS 6154 during the ODIS installation, please confirm that the following application opens. If not, please un-install and re-install ODIS.

Click the Windows Button > All Programs > XS_D_PDU_API_OS


- XS D PDU API Tester

3.0 – Import Security Certificate to Application

Brand-specific diagnostic data must be downloaded from the VWAG Group Services web-server. To enable this, the security certificate obtained from erWin>Vehicle Diagnostic Step 2 must be imported to the ODIS Service application.

The diagnostic device's **hardware key must be entered as a password** during the certificate importation process.

1. From the Windows desktop, right-click the **Offboard Diagnostic Information System** icon, and select **Run as administrator**:




Wait while the application starts:



Service Information

2. Select **Installing the client certificate**:



Offboard Diagnostic Information System PostSetup

PostSetup - Configuration data input


URL:

User name:

Keyword:

To complete your installation, the brand- and language-dependent components must be added.

3. Click **Select**:



Client Certificate

Importing certificates

Group system access with authorization requires a certificate in the ODIS Key Store. Select the certificate in the file system and import it.


Certificate:

Password:

Browse to the certificate location. This is the certificate you received via e-mail from the VWGoA Dealer Fax


Service Information

4. **Select / highlight** the certificate (.pfx) file and then click **Open**:




Note:
DO NOT double-click the certificate file in its saved location!

5. Ensure the **certificate file directory path** appears in the **Certificate** import window:



Note: You would of saved his hardware ID when completing **Step 2 or 3** on **erWin > Vehicle Diagnostics**. If you don't have it, go back to this step in erWin and click the Hardware ID generator.


6. **Select** and **Copy** the first 32 characters (only) of the **hardware key**. Example:




The characters are saved in Windows "clipboard" memory.

Service Information

7. **Paste** the 32-characters copied above into the **Password:** entry field, and then select **Import**:




8. Click **OK**:




3.1 – Diagnostic Database Download & Installation – “Post-Setup”

1. Click the **Forward Arrow** button:



Service Information


2. Click the **Forward Arrow** button:




Notes:

- **English is the default language selection. If this is a Lamborghini or Bentley installation select English (GB)**

3. **Wait** while the connection is established:



4. Click the **Forward Arrow** button:




Notes:

- **The diagnostic data version information illustrated here *is an example only!* Versions are updated regularly.**
- **The version(s) listed in the example reflect the Brand(s) associated with the license file. The association is based on the dealership's status, either **Single** or **Dual**.**

Service Information

5. **Wait** while the diagnostic data download and installation takes place:



The **Progress dialog** window may appear to stall or lock at times during this process. This is normal. **Please be patient!**

Download times depend on single brand or dual brand data (**dual = longer**), the dealership network download speed and network traffic (**slower Mbps + busy = longer**).

1. **Read and close** the **Release Notes** window.
2. **Read the Warnings/notes information, scroll down and click OK.**

The **ODIS Service** main window appears.

The **VW brand design** is displayed by default.

4.0 – Post-Setup Configuration

Prior to placing the diagnostic device into service, a number of configuration steps are required. Configurations take place via the **Admin** operating mode. Settings can be changed at any time.

4.1 – Administration - General

The following subsections describe configurations using the **Admin > General** operating mode.

1. From the ODIS Service main screen, select **Admin**:




Service Information

The **General** category tab appears first by default. Available function / configuration subcategories are listed in the left-hand display menu of each tabbed category.

4.1.1 – Update

The **schedule for automatic updates** is configured with the **Update** function.

1. Select **Update**, and then review the available update schedule settings:
2. Configure the update **cycle** and **time** appropriate for your facility: Click **Save / Yes**:




4.3 – Administration - Connections

The following subsections describe configurations using the **Admin > Connections** operating mode.

4.3.1 – Brand Settings Data

The connection to **VWAG Group Services** (to transmit GFF logs, etc.) is configured via **Brand settings**.

1. From the **Admin** operating mode main screen, select the **Connections** tab. The **Brand settings** subsection is displayed first by default:



Service Information

2. Change the Connection type in the dropdown menu(s) from **CPN** to **Internet**. Click **Save / Yes**:

Brand Settings

Details about Brand Settings

Brand to configure

Selection: Volkswagen

Connection types

for Audi: CPN

for Volkswagen: CPN

IMPORTANT!
Failure to change the connection type from **CPN** to **Internet** will result in the inability to download online updates!

Save

5.0 – Bentley URL Changes

THE REMAINING STEPS ARE FOR BENTLEY INSTALLATIONS ONLY

Click on **Admin > Connections > Group system: Logon** and ensure your URL's match what's below

General Save locations Support Connections Measurement Certificate Measuring technology action

Brand Settings

Group system: Logon

Group System: GFF

Group System: Els...

Group System: Ca...

Group System: DISS

Group System: eS...

Details about Group system: Logon

URL to DSS View: https://odisinfomedia.vwhub.com/Technical/DiagnosticSessionViewService

URL to DSS Logon: https://odisinfomedia.vwhub.com/services

URL to Logon: https://odiscert.vwhub.com/LOGON/LOGONService.asp

Service Information

Click on **Admin > Connections > Group System: GFF** and ensure the URL match what's below

General	Save locations	Support	Connections	Measurement	Certificate	Measuring technology action
---------	----------------	---------	-------------	-------------	-------------	-----------------------------

Brand Settings

Group system: Log...

Group System: GFF

Group System: Els...

Group System: Ca...

Group System: DISS

Group System: eS...

Mirror Server 2

Details about Group System: GFF

PinService

https://odiscert.vwhub.com/PIN/PINService.asp

RepairHints

https://odiscert.vwhub.com/Service42/RepairHints.asp

SVMService

https://odiscert.vwhub.com/svmvw/svmvwservice.asp

ProtoService

https://odiscert.vwhub.com/PROTO/PROTOService.asp

Click on **Admin > Connections > Mirror Server2** and ensure the URL match what's below

General	Save locations	Support	Connections	Measurement	Certificate	Measuring technology action
---------	----------------	---------	-------------	-------------	-------------	-----------------------------

Brand Settings

Group system: Log...

Group System: GFF

Group System: Els...

Group System: Ca...

Group System: DISS

Group System: eS...

Mirror Server 2

Details about Mirror Server 2

Access data

Mirror Server URL

https://mirrorserver2.vwhub.com/dav/


Mirror Server user

Mirror Server password


Timeout

Timeout [s]


120




Click next




Click next





Click Next




Double check to make sure selecting standard pc/notebook



Select Pass Thru





Select next and watch the magic happen.

Magic takes 2-3 hours

Minimum Software / Hardware Requirements

4GB of RAM CPU better than Pentium 4 @ 2GHZ

80GB of free hard drive

15" Monitor with 1024 x 768 resolution

Microsoft Windows 7 Professional 64 bit or Microsoft Windows 7 Enterprise 64 bit with SP1

Connectivity Requirements

Local Area Network internet connection with a minimum of 2Mbit per second download / upload speed.

Mozilla Firefox 4 or higher Microsoft Internet Explorer 7 or later

As least 1 free USB port

Network connection to the internet with no proxy connections


Pass - Through Tool (PTT) that is SAE-J2534 compatible

What is J2534 and Pass-Thru Programming?

J2534, also known as Pass Through, ensures that independent repair shops can work on modern cars and have cost-effective access to information and ECU programming downloads from vehicle manufacturer when required.

SAE J2534 is a communications standard adopted by vehicle manufacturers that enables compliant devices to reprogram vehicle ECUs. US legislation requires vehicle manufacturers to make vehicles, diagnostic and reprogramming applications that are compatible with J2534 devices, such as the Drew Technologies CarDAQ-Plus 2 (only available in North America) interface.

Most modern cars can now be reprogrammed using the J2534 standard. Our products and services enable this without the need for separate, expensive OE tools for each brand.



Start up screen of Odis




Notice the Key with the question mark on it



When using a j2534 device the key is no recognized, no need to worry about this it how Volkswagen wrote the program when not using their diagnostic head.

DREWTECH PRODUCTS

CarDAQ-Plus 2+ and CarDAQ-M+ are designed for all OEMs, while each MongoosePro+ is designed to be OEM-specific. If your shop focuses on one particular make, MongoosePro+ will fit your needs. However, if you do all makes/all models, CarDAQ-Plus 2+ or CarDAQ-M+ will be the best choice for you.

	 CarDAQ-Plus 2+	 CarDAQ-M+	 MongoosePro+
OEMs Supported			
BMW/Mini	X	X	X
Chrysler	X	X	X
Daewoo	X	X	
Ford	X	X	X
GM	X	X	X
Honda/Acura	X	X	X
Hyundai	X	X	
Isuzu	X	X	
Kia	X	X	
Mazda	X	X	
Mercedes Benz	X	X	
Mitsubishi	X	X	
Nissan/Infiniti	X	X	
Subaru	X	X	
Toyota/Lexus/Scion	X	X	X
Volvo	X	X	
VW/Audi	X	X	X
Product Features			
USB version 1.1 and higher	X	X	X
J2534 Support	X	X	X
Bluetooth option available *	X		X

This is the 5054a Volkswagen/Audi head and can only be used on a windows 7 Pc



This is the 6154 Volkswagen/Audi head and is used with windows 10





The Internet



Importer: — Dealer: — RO: —	VIN: — Engine: —	 	 Audi
-----------------------------------	---------------------	------	-----------------

Welcome to Diagnosis

Goal: full diagnostic functionality Once the vehicle has connected and diagnosis has started, vehicle identification and evaluation of the DTC memory will take place. Then the "Guided Fault Finding" and "Guided Functions" will be available for vehicle diagnosis. If you would like to work without a warranty order, you also have the option to use QBD.

Connection to the vehicle established
Ignition status not recognized
[Starting diagnosis](#)

Copyright by Volkswagen AG. All rights reserved, especially but not limited to duplication, distribution and making publicly available.

Operating modes ^

- Diagnosis**
- OBD
- Flash
- Measurement
- Info
- Admin


Log ▾

Data ▾


Extras ▾

Help ▾

Activate Windows
 Go to Settings to activate Windows



From Admin change connection type from cpn



To internet

Control Units in List format

Offboard Diagnostic Information System Service - 4.3.3

Importer: 444 VIN: CPMB 2.0i TFSI / 162 kW
 Dealer: Remaining runtime: 364 Tage, 22h
 RO: —

Control modules

Control module list (56 entries)

Address	Event	Name
0010	0	Parking Assistance 2 (Not yet identified) (— — —)
0020	0	High Beam Assistance (Not yet identified) (— — —)
0030	0	Special Function 2 (Not yet identified) (— — —)
0040	0	Air Conditioning Compressor (Not yet identified) (— — —)
00C0	0	Actuator For Exterior Noise (Not yet identified) (— — —)
0001	0	Engine Control Module 1 (Not yet identified) (— — —)
0051	0	Drive Motor Control Module (Not yet identified) (— — —)
0002	0	Transmission Control Module (Not yet identified) (— — —)
0022	0	All Wheel Control (Not yet identified) (— — —)
0042	0	Door Electronics Driver Side (Not yet identified) (— — —)

Networking diagram: Control Module List Components List DTC memory list Equipment list


Diagnosis Display... Sorting...

Operating modes: Diagnosis OBD Flash Measurement Info Admin

Log Data Extras Help

Activate Windows Go to Settings to activate Windows.

Diagnostic enhancement was started... Read control modules: [02]




Control Unit List

- Access and Start Permission - 05
- Additional and Auxiliary – 18
- Air Conditioning - 08
- Airbag – 15
- Automatic Light Switch - 49
- Automatic Vertical Headlight Switch – 55
- Auxiliary Fuel Tank – 58
- Auxiliary Heater – 7D
- Battery Charger - 71
- Battery Regulation – 61
- Brake Booster – 23
- Brake Booster Assistance – 43
- Brake Electronics – 03
- Central Locking – 35
- Climate Control Unit Rear – 28
- Clutch Electronics – 12
- Control Head LR – 5E
- Control Head RR – 4E
- Convenience System Central Module – 46
- Dash Panel Insert – 17
- Diagnostic interface For Data-Bus – 19
- Diesel Pump Electronics – 41
- Display Control Unit – 07
- Display Control Unit Rear – 27
- Distance Regulation – 13
- Driver Identification – 1D
- Driver Side Door Electronics – 42
- Drivers Side Boarding Assistance – 63
- Drivers Side Seat Adjustment Rear – 48
- Electro-Drive – 51
- Electronic Central Electrics - 42
- Drivers Side Boarding Assistance – 63
- Drivers Side Seat Adjustment Rear - 48
- Electro-Drive – 51
- Electronic Central Electrics – 09
- Electronic Central Electrics – 4F
- Electronic Roof Controls – 26
- Engine Electronics – 01
- Engine Electronics Conjunction – 31

- Engine Electronics II – 11
- Engine Electronics III – 21
- Four Wheel Drive Electronics – 22
- Immobilizer – 25
- Indicator Unit in Instrument Panel Insert – 7E
- Information Electronics I – 5F
- Information Electronics II – 7F
- Interior Monitoring – 45
- Lane Change Assistant – 3C
- Lane Retention Assistant – 5C
- Left Rear Door Electronics – 62
- Light Control Left – 29
- Light Control Right – 39
- Locking Electronics – 32
- Media Player Position 1 – 0E
- Media Player Position II – 1E
- Media Player Position III – 2E
- Media Player Position IV – 3E
- Navigation – 37
- Operation – 5D
- Parking Aid – 76
- Parking Aid II – 10
- Parking Brake – 53
- Passenger – Side Seat Adjustment - 06
- Passenger - Side Door Electronics – 52
- Passengers Side Boarding Assistance – 73
- Radio – 56
- Radio tuner Digital – 0F
- Radio Tuner Satellite – 1F
- Rear Lid Electronics – 6D
- Rear Seat Adjustment – 66
- Rear Spoiler – 54
- Rear View Camera system – 6C
- Right Rear Door Electronics – 72
- Roof Display Control Head - 6E
- Roof Electronics – 38
- Seat and Steering Column Adjustment – 36
- Self-Leveling Suspension - 34
- Sliding Door Left – 0D
- Sliding Door Right – 78
- Sound System – 47
- Special Function – 3D

- Stabilizers – 64
- Steering Assistance - 44
- Steering Position – 04
- Steering Wheel Electronics – 16
- Suspension Electronics – 16
- Telematics – 75
- Telephone – 77
- Towing Protection – 59
- Traction Control – 24
- Trailer Function – 69
- Transmission Electronics – 02
- Tv Tuner – 57
- Tv tuner Digital – 2F
- Tire Pressure Monitoring – 65
- Tire Pressure Monitoring II – 4C
- Vehicle Control System – 74
- Vehicle Position Detection– 1C
- Voice Amplification – 2D
- Voice Control – 67
- Wiper Electronics – 68



Control Units with fault codes are highlighted in red

KLH_08

Control Units with no faults are out lined in black

HDE_6D

Control Unit that might not be fitted or off-line have a gray out line

EPH_76

List two control units that are on-line with no faults

1.

2.

List two control units that are off-line


1.

2.

Your customer comes in with check engine light and said he read on the internet there is an update for his engine control unit. He went to AutoZone and they gave him a print out of his fault codes.


2007 Volkswagen Touareg

Fault Code – P0420

**Volkswagen**

Home | About erWin | Search | Vehicle Diagnostics | Reprogramming | Security Professionals Key Program | My erWin

Welcome to erWin



Home

erWin contains all published service information from Volkswagen Group of America, as well as any additional information necessary to help the aftermarket service provider or VW owner to service VW vehicles.

[Click here for Genuine VW Parts Information](#)

[New Repairlink Wholesale Parts Program](#)

Login

User Name:

Password:

[Password Forgotten](#)

Info

Not logged in

GTB | Legal Information | Data Protection



Volkswagen

[Home](#) | [About erWin](#) | [Search](#) | [Vehicle Diagnostics](#) | [Reprogramming](#) | [Security Professionals Key Program](#) | [My erWin](#)

Search

Search

Search Parameter

[Guided Search](#) [Manual Search](#) [Vehicle Identification Number](#)

Please enter a VIN.

VIN*

Category 1

[Category 1] ▼

▶ Search

▶ Reset

Search Results

[Service Information](#) [Technical Bulletins](#) [Vehicle Data](#) [Campaigns](#)

Please perform a [Guided Search](#), [Manual Search](#) (both **with Model Year and Model** selected) or a [Vehicle Identification Search](#).

Login

Logged in as
live52

▶ [Log Out](#)

▶ [Change password](#)

Info

Logged in as:
farsightlive52

Your subscription expires in:
2 hrs. 40 mins.

Current Search Parameter:

Keyword: -
VIN: -
Year: -
Model: -
Engine: -
Trans: -
Cat. 1: -
Cat. 2: -

Put in your Vin or manually build your vehicle.



Search

Search

Search Parameter

[Guided Search](#) [Manual Search](#) [Vehicle Identification Number](#)

The Guided Search allows you to find documents based on the model year, model, and selected category.

If you have the vehicle identification label, use the [Manual Search](#).

Please note: Routan Pass-Thru reprogramming solutions are available at <http://www.TechAuthority.com>. When searching for a flash file using the Year/Model/Engine dropdowns, select RT in the Model dropdown to see the available RM flash files.

For acronym definitions, refer to the [Acronym Glossary](#).

For a list of all VW vehicles, refer to the [build guide](#).

Model Year: 2007
Model(s): Touareg [TLA] (2003 - 2007)
Category 1: Repair Manual
Category 2: Engine

[Search](#)

[Reset](#)

Search Results

[Service Information](#) [Technical Bulletins](#) [Vehicle Data](#) [Campaigns](#) [iWire](#)

Filter

Component: [Component]

Result

218 items found, displaying 1 to 25.

[First/Prev] 1, 2, 3, 4, 5, 6, 7, 8 [Next/Last]

Number of items per page: 25

Issue Id	Topic
2019023/111	0-0-0 - Technical Bulletin Recent Releases - January Vehicle service / Vehicle diagnosis / Control modules, services

Login

[Log Out](#)
[Change password](#)

Info

Your subscription expires in:
2 hrs. 23 mins.

Current Search Parameter:

Keyword: -
VIN: -
Year: 2007
Model: Touareg
Engine: -
Trans: -
Cat. 1: Repair Manual
Cat. 2: Engine

The Guided Search is based on specific vehicle data.

Example:

- Model Year
Select the model year, e.g. 2005
- Model
Select the models, e.g. Jetta [1K2]
- Category
Select a category e.g. Electrical System

Select Technical Bulletins

Service Information Technical Bulletins Vehicle Data Campaigns iWire

Filter
 Component Engine
 Damage group [Damage group]

Result
 48 items found, displaying 1 to 25.
 [First/Prev] 1, 2 [Next/Last] Number of items per page: 25

Issue Id	Topic
2019023/111	0-0-0 - Technical Bulletin Recent Releases - January Engine / Engine operation / Functionality
2002412/7	00-08-04 - Sealants, Liquid Gasket/Lubricants (Silicone) Engine / Engine operation / Functionality
2045492/2	00-16-01TT - Contacting the Parts Helpline Engine / Engine operation / Functionality
2045803/2	00-16-02TT - Mandatory Fastener Replacement Engine / Engine operation / Functionality
2049386/1	00-17-03TT - Various Scan Tool Issues Engine / Operation, engine control / Functionality
2033846/10	00-17-13 - Fuel Additive to Help Prevent Sporadic Misfire Faults (Gasoline Engines Only) Engine / Engine operation / Functionality
2024504/2	01-10-14 - Update Programming to Eliminate DTC P0601 Stored in ECM Fault Memory Engine / Engine operation / Functionality
2016182/5	01-11-11 - MIL ON, DTC P129F and or P310B Stored in ECM Fault Memory Engine / Engine operation / Functionality
2028517/1	01-12-04 - Diagnostic Misfire Assistance after performing Campaign 28F/P1 (Gasoline Engines Only) Engine / Operation, engine control / Control modules, services
2019434/3	01-14-05 - MIL ON, DTCs P0325 or P0327 Stored in ECM Fault Memory Engine / Engine operation / Noises, vibrations
2014077/9	01-14-17 - Update Programming to Eliminate DTC P0601 Stored in DTC Memory Engine / Operation, engine control / Functionality
2037740/1	01-14-20 - Update Programming, MIL ON, DTCs P0420, P0430 Stored in ECM Fault Memory Engine / Operation, engine control / Control modules, services

Model	Engine	Old Software Part No.	Old Software Version	New Software Part No.	New Software Version	SVM Code
Touareg	3.6L	03H906032AG	2533	03H906032AG	6651	35B1
	BHK		0689			
			0212			
Touareg	3.6L	03H906032S	1558	03H906032S	7873	35B1
	BHK		1489			
			0554			
			0516			
			0301			
Touareg	3.6L	03H906032CB	1667	03H906032ED	7874	35B1
	BHK		1380			
Touareg	3.6L	03H906032ED	3259	03H906032ED	7874	35B1
	BHK		2703			
			2443			


If your engine control unit part number is 03H906032CB with software version 2443 do you need an update?

If your engine control unit part number is 03H906032AG with software version 9097 do you need an update?

If your engine control unit part number is 03H906032LP with software version 3259 do you need an update?


Where do we enter the svm code?







The **Test plan** tab contains a table with available tests. This table has two columns.


Status: this column indicates the status of the test by means of a symbol.


 This symbol indicates that the status is "Test not performed".

 This symbol indicates that the status is "OK". This test was successful.

 This symbol indicates that the user canceled a test.

 This symbol indicates that the status is "not OK". The test failed.


 This symbol indicates that the status of the program could not be determined.

 This symbol indicates that the diagnosis was completed and the component was repaired.


Used car with no keys how to program keys

2009 Audi a4 2.0t


No fault codes




Select Special Functions




Select Immobilizer, servicing




In Immobilizer Servicing you can replace Engine control units, Transmission control units, Steering lock control units and Comfort system control unit.




If you have no key on function turn the emergency flashers on to wake up the data bus.



Make sure your vin is correct!



Enter your password



Enter the number of key you want to do. All keys must be programed at the same time.

Offboard Diagnostic Information System Service - 4.3.3

Importer: 444 VIN: CPM6 2.0i TFSI / 162 kW
 Dealer: — Engine: 864 Tage, 22h
 RO: — Remaining runtime:

Control modules: DISS TSB Test plan Operation Special Functions

Tests for the entire vehicle

Status	Tests
	** - Functions - Immobilizer 5
	^^ - General system description (immobilizer V)
✓	^^ - Immobilizer, servicing
	^^ - Immobilizer status of all control modules
	01 - ECM - Immobilizer overall status (RG.23/24)
	02 - TCM - Immobilizer overall status (RG.35/38)
	05 - Electronic Steering Lock - Immobilizer overall status
	05 - IMS - Immobilizer overall status
	11 - ECM 2 - Immobilizer overall status (RG.23/24)
	51 - Electro drive - Immobilizer ASAM overall status

Perform test... Display documents

Test was ended.


Operating modes: Diagnosis, OBD, Flash, Measurement, Info, Admin, Log, Data, Extras, Help

✓ This symbol indicates that the status is "OK". This test was successful.


Test Plan



Testing system not listed in fault codes




Older Vehicles with immobilizer inside cluster functions



Key programming

1. Go to the engine ECU -> click extract pin and wait for the pin code to be extracted and write this down
2. Go to access and start ECU
3. Turn the key to the s-contact position
4. Click manual functions -> security access -> level 3
5. Edit the code to the pin code from the engine ECU and click login
6. Turn the key to the terminal 15 position
7. Click adaptations -> channel 21

Live Data Readings



Key Adaptation Tip - KESSY Equipped

Model(s) Year Eng. Code Trans. Code

VIN Range

From

VIN Range To Golf/GTI, EOS, Jetta Sedan, Jetta SportWagen, Tiguan

2011-2013 Passat, Beetle 2012-2013

Technical Background

Note:

All keys must be present during key adaptation. Immobilizer reader coil is ALWAYS located in the steering column. DO NOT remove Start/Stop button mounted in center console to access reader coil.

When adapting keys on a vehicle equipped with KESSY, it is recommended to remove the immobilizer reader coil from behind round cover on steering column trim and insert key inside the reader coil. The steering column trim does not need to be completely removed to access reader coil. For vehicles with the Start/Stop button on the steering column, the Start/Stop button assembly can be removed from column trim without disassembling trim. Start/Stop button connector must be disconnected to allow reader coil to be removed from around button assembly. Start/Stop button should be reconnected during key adaptation.



Technical Service Bulletin Transaction No.: 2050648/2

01-18-02TT - Cruise Control Inoperative with possible DTC P1647 Release date: Mar 8, 2018

Condition

Cruise Control Inoperative with possible DTC P1647

Model(s) Year Eng. Code Trans. Code

VIN Range

From

VIN Range To

Golf, GTI 2015-2017

Technical Background

Cruise control inoperative, with fault P1647 stored in the Engine Control Module -J623-.

Production Solution

NA.

Service

- Connect a Scan tool.
- Go to Special Functions.
- Go to SVM Software Version Management.

Perform the following tests:

Control module software configuration and FES function clearing system.

Select Re-create Function for AW 19.

2006 Audi A6 MMI

Most Bus Test

How Ring Break Diagnosis Works

After ring break diagnosis is initiated, the diagnosis manager sends an impulse to the control modules over the diagnosis wire.

In response to this impulse, all of the control modules in the ring use the transmitters in their fiber-optic transceivers to send light signals through the fiber-optic cable.

At the same time all control modules check:

- Their voltage supply and internal electrical functions
- Receipt of the light signals from the previous control module in the ring

Each control module connected to the MOST fiber-optic data bus answers according to timing programmed into the software.


Using the timing between the start of the ring break diagnosis and receipt of the answer, the diagnosis manager recognizes which control module sent the answer.


The control modules connected to the MOST fiber-optic data bus send two messages after the start of the ring break diagnosis:

- "Control module is electrically OK" means that the electrical functions of the control module, such as the voltage supply are OK
- "Control module is optically OK" means that it receives the light signal through its photodiode from the control module that precedes it in the ring


From this information the diagnosis manager can recognize:



- Whether there is an electrical fault in the system (voltage supply faulty)
- Between which of the control modules the optical data transmission is interrupted





Odis Checks who is on bus.





Odyssey will now tell you who took too long to answer

Controller	Electrical	Optical
19-CAN Gateway	OK	OK
07-Control Head(High/D3)	OK	OK
0E-Media Player 1	OK	OK
77-Telephone	OK	OK
47-Sound System	OK	ERROR
67-Voice Control	OK	ERROR
56-Radio	OK	OK
37-Navigation	OK	OK
0F-Digital Radio(SAT)	OK	OK

Don't forget your Most bus test cable!



Master Functions

J533 is the master for:

- Drivetrain CAN continued operation
- MOST ring break diagnosis
- Data bus system Sleep and Wake-Up operation

Drivetrain CAN Continued Operation

Operation of several control modules continues after the ignition is switched OFF. J533 broadcasts a command to end operation to the Drivetrain CAN following an after-run period.


MOST Ring Break Diagnosis

J533 is the diagnosis manager for the MOST bus (discussed later in this book). The interface is responsible for Ring Break Diagnosis and sends the diagnosis data in the MOST bus to J533.

Ring Break Diagnosis for the MOST bus is initiated with a Final Control Diagnosis Output Check Diagnosis in J533.

Data Bus System Sleep and Wake-Up Operation

J533 is the master for Sleep and Wake-Up modes. When all the control modules on the Convenience CAN indicate "sleep readiness," the Gateway sends the sleep command to the CAN-bus and the control modules change to sleep status. The sleep status of the individual control modules and bus systems can be read in the measuring value blocks of J533.



Audi A8 mmi coding




(07) Display Control Unit

adaptation channel 1

Channel 001: Installation List I (MMI Functionality)

- +00001 = Adaptive Cruise Control installed (PR-8T4)
- +00002 = Ambient Lighting installed (PR-QQ1)
- +00004 = Acoustic Parking System Front installed (PR-7X2)
- +00008 = Acoustic Parking System Rear installed (PR-7X1/7X2)
- +00016 = Tire Pressure Monitoring System installed (PR-7K3/7K4/7K5)
- +00032 = Sunroof installed (PR-3FE/3FR)
- +00064 = Adaptive Air Suspension installed (PR-1BK)
- +00256 = Rain Sensor installed (PR-8N3)
- +01024 = Seat Adjustment Front installed (PR-3PN)
- +02048 = Seat Adjustment Rear installed (PR-5Z1)
- +04096 = Multi-Function Steering Wheel installed (PR-1XW)
- +08192 = Lane Change Assistant installed
- +16384 = Lane Holding Assistant installed


Document display




MMI system reset starting

A MMI-system-reset offers simple immediate help during a software-crash of the MMI-system.

- Hold function button 1 (setup), control knob 2 and right upper control button 3 simultaneously until the MMI-system is switched-off.
- Release buttons => MMI-system restarts.


NOTE:

For right hand steering the button combination is mirror reversed.



Print

Close

Reset MMI after any work performed.

Newer MMI System Reset and Functions

Screenshot

A screenshot is a snapshot of the current display on the MMI screen. To save it, an SD card has to be inserted in the SDF card reader and the following buttons pressed and held one after the other:

- ▶ Bottom left softkey
- ▶ Bottom right softkey

To indicate that the screenshot is being saved, the current screen display disappears momentarily (white screen). Screenshots cannot be created on the Entry MIB and Entry plus MIB.



618_065

Key combination for screenshot

System reset on Entry MIB

To restart the system on the Entry MIB, the following buttons must be pressed simultaneously and held for at least five seconds:

- ▶ ON/OFF switch
- ▶ Forward button



Key combination for reset

618_066

Key combination for Service on E380

System reset

To restart (reset), the following buttons must be briefly pressed simultaneously:

- ▶ Rotary pushbutton
- ▶ Top right soft key
- ▶ MENU



618_063

Button combination for system reset

Engineering menu

The Engineering menu is required, for example, to install a software update. To access the menu, the following buttons must be pressed one after the other and held down:


- ▶ BACK
- ▶ Top left softkey



618_064

Button combinations for the Engineering menu

Climate Control Head Replacement




Under the Special functions select Control Head Climate Control component protection to bring control unit in to service.

If you still have a problem with a/c now working after control head replacement check your fault codes, if no fault codes look for live data reading with a/c switched on and look at chart below.


Ac Shut off Codes

- 0 - no ac shut off Compressor should be running
- 1 - Excessive refrigerant pressure too much R134a or faulty high-pressure switch
- 2 - Cooling fan fault Possible faulty fan or power supply to fan
- 3 - Refrigerant pressure too low Check R134a quantity, possible leak
- 5 - No engine speed detected Start engine/check engine speed live data
- 6 - Econ button depressed Switch of econ button
- 7 - Air conditioning off No blower speed selected
- 8 - Outside air temp too low Below 2.5 degrees, check live data
- 10 – low voltage Vehicle voltage below 9.5 volts
- 11 – Engine temperature too high Temp above 118 degrees, Temp sender fault
- 12 - Engine control unit Off ECU turned off, check engine faults
- 13 – High Voltage Vehicle voltage over 16 volts
- 15 - Coding Incorrect Check engine and ac coding if correct
- 16 - Compressor activation issue Check wiring to compressor
- 17 – Pressure sensor fault Checking pressure sensor and wiring
- 18 – Speed switched off Engine Rpm over 3000 and vehicle speed below 10 mph
- 19- Electronic central electrics off check for faults in electronic central electrics
- 20 – Output test Exit output test mode


Transmission Control Unit Unlocking




From the test plan select TCM locked, checking




The tool will go through a few checks




Then it will check the J518 access/start control unit



It will let you know the Tcm is locked



Then it will want to match the transmission to the immobilizer



Reading immobilizer data then you all done.

Non-DSG Transmission Basic Settings

1. Select Manual Functions
2. Select Adaptions
3. Adaption Channel 01

DSG Transmission Basic Settings

Prerequisites:

Selector Lever in P

Engine ON (Idling) for one minute or more

Brake Depressed at all times

Parking brake

Engaged Calibration

1. Select Manual Functions
2. Select Adaptions
3. Adaption Channel 61
4. Toggle Basic settings
5. Wait for Transmission to stop Making noise

Synch, Point, Measurement

6. Select Manual Functions
7. Select Adaptions
8. Adaption Channel 60

9. Toggle Basic settings
10. Wait for Transmission to stop Making noise

Clutch Adaptation

For Control Module Software Lower than 0800


11. Select Manual Functions
12. Select Adaptions
13. Adaption Channel 62
14. Toggle Basic settings
15. Wait for Transmission to stop Making noise

For Control Module Software Higher than 0800

16. Select Manual Functions
17. Select Adaptions
18. Adaption Channel 67
19. Toggle Basic settings
20. Wait for Transmission to stop Making noise


Clear fault codes and road test after basic setting

Access/Start Module J518




Sometimes you may have to hold the high beams on to wake vehicle


Select enable Immobilizer in test plan




Select continue




Hold High beams again



Select Adapting access start



Input clients name



Input your password and your module will be matched

Audi A8 2003>

Technical Service Bulletin

Transaction No.: **2019494/4**

96 Control unit J518 cannot be adapted to the immobilizer

Release date: Dec 2, 2010

Condition

REVISION HISTORY		
Revision	Date	Purpose
4	-	Revised <i>Service, Customer Codes, Warranty</i>
3	8/12/2010	Revised header data (Controlling TSB display in ElsaWeb)
2	9/29/09	Revised header data (Added MYs)
1	12/18/2008	Original publication

After replacing either the control unit for access and start authorization J518 or the steering column, J518 cannot be adapted to the immobilizer.

Technical Background

Control unit for access and start authorization J518 with software version below 160 are affected.

Production Solution

New software for control unit for access and start authorization J518.

Service

Replace both components (the steering column and the control unit for access and start authorization J518) at the same time when your analysis identifies one of the two components as inoperative.



Tip: The two new control units must be installed and programmed at the same time. If they are done one after another, the programming will fail.

Warranty

Claim Type:	Use applicable claim type. If vehicle is outside any warranty, this Technical Service Bulletin is informational only.		
Service Number:	9666		
Damage Code:	0039		
Labor Operations:	Remove and install steering column	4823 1900	220 TU

	Remove and install front seat	7201 1900	70 TU
	Replace keyless access control unit	9666 5550	40 TU
Diagnostic Time:	GFF	0150 0000	Time stated on diagnostic protocol (Max 75TU)
	Road test prior to service procedure	No allowance	0 TU
	Road test after service procedure	No allowance	0 TU
	Technical diagnosis at dealer's discretion (Refer to Section 2.2.1.2 and Audi Warranty Online for DADP allowance details) Canadian Dealers: Please follow CAWP-09-02 for diagnosis process.		



Instrument Cluster Replacement

When replacing Instrument cluster, you will need the following

1. All keys that you want to be programmed to the vehicle
2. Pin number for Instrument Cluster Old and New
3. Coding for instrument Cluster

Immobilizer 1 Instrument Cluster

1. Select coding
2. Code Instrument Cluster to options on vehicle through manual coding or descriptive coding.
3. Select manual Functions
4. Select adaptations
5. In adaption channel enter 9

6. In actual value enter the mileage of the vehicle, now with the mileage entered if the value is 65297, you must enter 6529 for correct mileage to be entered in to the vehicle.
7. Press test value and look at instrument cluster mileage display, mileage should be visible
8. Press save and go to Key Coding to program all keys

(For entering mileage go to manual functions and login in with 13861, once login correctly go to adaption and adaption channel 9 enter the mileage and hit test valve look at cluster and check if mileage is correct)

Immobilizer 2

1. Extract Pin from Instrument Cluster
2. Code Instrument cluster to options on vehicle
3. Select manual functions
4. Select Login
5. Login with pin number from instrument cluster
6. Select adaptations
7. Enter 00 in adaption channel and learnt values will be erased
8. Select Key Coding and program all keys


(For entering mileage go to manual functions and login in with 13861, once login correctly go to adaption and adaption channel 9 enter the mileage and hit test valve look at cluster and check if mileage is correct)



Immobilizer 3

1. Extract pin Numbers from both Instrument clusters
2. Install new cluster
3. Select manual functions
4. Select login enter pin code for this cluster
5. Select Adaptions

6. In adaption channel enter 50
7. In actual value enter pin number from old cluster
8. Select test value
9. Vehicle Vin Number should be displayed in data 1
10. Press save once Vin is displayed
11. Select key coding and program all keys

Obtaining Radio Code





Offboard Diagnostic Information System Service - 4.3.3

Importer: 444 VIN: 3VW
 Dealer: --- Engine: BRM 1.9l TDI/74 kW
 RO: --- Remaining runtime: 349 Tage, 6h

Control modules Orders DISS TSB Test plan Operation Special Functions

Networking diagram

Graphic display ended

Networking diagram Control Module List Components List DTC memory list Equipment list

Diagnosis Display... Sorting...

Operating modes

- Diagnosis
- OBD
- Flash
- Measurement
- Info
- Admin

Log

Data

Extras

- Search
- Diagnostic Interface
- Road Test
- Update
- Connection Test

Help

Info

Offboard Diagnostic Information System Service - 4.3.3

Importer: 444 VIN: 3VW
 Dealer: --- Engine: BRM 1.9l TDI/74 kW
 RO: --- Remaining runtime: 349 Tage, 6h

Control modules Orders DISS TSB Test plan Operation Guided Functions

Networking diagram

Radio

- 56 - Adapt driving school function
- 56 - Adapt reception optimization for weak FM areas
- 56 - Code radio functions
- 56 - Evaluate radio coding
- 56 - Radio code query (Rep.Gr. 91)
- 56 - Radio output diagnostic test mode
- 56 - Read measured values for radio
- 56 - Read out field intensity of current station
- 56 Activate transport lock of CD changer in RCD 500

Perform Cancel

Radio

Networking diagram Control Module List Components List DTC memory list Equipment list

Diagnosis Display... Sorting...

Operating modes

- Diagnosis
- OBD
- Flash
- Measurement
- Info
- Admin

Log

Data

Extras

- Search
- Diagnostic Interface
- Road Test
- Update
- Connection Test

Help

Info

Offboard Diagnostic Information System Service - 4.3.3

Importer:	444	VIN:	3VW
Dealer:		Engine:	BRM 1.9l TDI/74 kW
RO:	---	Remaining runtime:	349 Tage, 6h

Control modules Orders DISS TSB Test plan **Operation** Special Functions

Radio code query
Enter customer data

In the following, information must be included on the job order:
- Enter the name of the client:

Accept

Help Cancel test

Test version

Operating modes

- Diagnosis
- OBDD
- Flash
- Measurement
- Info
- Admin
- Log
- Data
- Extras
- Search
- Diagnostic Interface
- Road Test
- Update
- Connection Test
- Help
- Info

Offboard Diagnostic Information System Service - 4.3.3

Importer:	444	VIN:	3VW
Dealer:		Engine:	BRM 1.9l TDI/74 kW
RO:	---	Remaining runtime:	349 Tage, 6h

Control modules Orders DISS TSB Test plan **Operation** Special Functions

Radio code query
Enter customer data

- Enter the country of origin of client:

444


Accept

Help Cancel test

Test version

Operating modes

- Diagnosis
- OBDD
- Flash
- Measurement
- Info
- Admin
- Log
- Data
- Extras
- Search
- Diagnostic Interface
- Road Test
- Update
- Connection Test
- Help
- Info



Control unit update list



A4 Golf Jetta Beetle B5 Passat								
Model Year	Model	Engine	Concern	Module Part #	New Part #	Updated Software	Technical	SVM or Disc
2002	Cabrio	2.0L ABA	P0102, P1128, P1296	037906018G	037906018G	V07	01-08-16	SVM 34E6
				037906018H	037906018H	V06	2014140	
1999-2001	Beetle	1.8T APH	P1176	06A906032B	06A906032S	5829	01-06-03	Replace ECM
				06A906032E	06A906032R	5828		
				06A906032A	06A906032Q	5827		
				06A906032C	06A906032P	5826		
1999-2001	Golf Jetta Beetle	2.0L AEG	WA Front Oxygen Sensor faults	06A906018ES	06A906018JJ	V01	WA00	3060
				06A906018ET	06A906018JK			
				06A906018FA	06A906018JL			
				06A906018FB	06A906018JM			
				06A906018EN	06A906018JN			
				06A906018EP	06A906018JP			
				06A906018EQ	06A906018JQ			
				06A906018ER	06A906018JR			
				06A906018J	06A906018JA			
				06A906018BJ	06A906018JB			
				06A906018BG	06A906018JC			
				06A906018BH	06A906018JD			
				06A906018CR	06A906018JE			
				06A906018CQ	06A906018JF			
				06A906018P	06A906018JG			
				06A906018AE	06A906018JH			
2001-2005	A4 Jetta GTI	1.8T AWW 1.8T AWP 1.8T AWD	P0420, P0442 or cold start misfires	06A906032DL	06A906032DL	0007	01-09-10 2010348	3061
				06A906032GH	06A906032GH	0007		
				06A906032HF	06A906032SL	0040		
				06A906032LQ				
				06A906032NL	06A906032SK	0040		
				06A906032HS				
				06A906032LP				
				06A906032NK				
				06A906032ML	06A906032SM	0040		
				06A906032PL				
				06A906032RN				

A4 Golf Jetta Beetle B5 Passat Continued									
Model Year	Model	Engine	Concern	Module Part #	New Part #	Updated Software		Technical Bulletin #	SVM or Disc
						Level			
2001-2004	Beetle	1.8T AWP 1.8T AWU 1.8T AWV	P0420 or P0442 Cold start misfires	06A997012	06A997012	9777	01-09-07 2014376	3005	
				06A906032QA					
				06A906032LS					
				1C0906032					
				06A997012A	06A997012A	9776			
				06A906032GA					
				06A906032KR					
				06A906032PR					
				06A997012B	06A997012B	9775			
				06A906032GB					
				06A906032KQ					
				06A906032PT					
				06A997012C	06A997012C	9778			
				06A906032KT					
				06A906032PS	06A906032EM	9774			
				06A906032EM					
				06A906032DN	06A906032FD	9773			
				06A906032FD					
				06A906032DP	06A906032FD				
2005	Beetle	1.8T BKF 1.8T BNU	P0420 or misfires on cold start	06A906032QT	06A906032QT	9784	01-08-10 2016958	3486	
				06A906032QS	06A906032QS	9785			
				06A906032RA	06A906032RA	9786			
1999-2002	Golf Jetta	2.8L AFP	N7 ECM Software for Catalyst Monitoring	021906018A	021906018A	6781	26E1	306B	
				021906018B	021906018B	6782			
				021906018K	021906018K	6758			
				021906018M	021906018M	6760			
				021906018Q	021906018Q	6759			
				021906018R	021906018R	6762			
				021906018S	021906018S	6761			
				021906018T	021906018T	6764			
				021906018AA	021906018AA	6763			
2002-2004	A4 Jetta	2.8L BDF	P0420 and/or Misfires	022906032BL	022906032BL	1479	01-08-14 2017553	3000	
				022906032BM	022906032BM	1480			
				022906032CR	022906032CR	1481			
				022906032CS	022906032CS	1482			
				022906032DM	022906032DM	1483			

A4 Golf Jetta Beetle B5 Passat Continued

Model Year	Model	Engine	Concern	Module Part #	New Part #	Updated Software		Technical Bulletin #	SVM or Disc
						Level			
2002-2004	A4 Golf	2.8L BDF	P0420 and/or Misfires	022906032BM	022906032BM	1480		01-08-22 2018669	3001
				022906032CS	022906032CS	1482			
				022906032DM	022906032DM	1483			
2000-2005	B5 Passat	1.8T ATW 1.8T AUG 1.8T AWM	Misfires at cold start or P0102, P1297, P0420 or P0441	4B0906018BH	4B0906018BH	0009		01-09-09 2005554 R5	3061
				4B0906018BG	4B0906018BG	0009			
				4B0906018BQ	4B0906018BQ	0004			
				4B0906018CL	4B0906018CL	0003			
				4B0906018CM	4B0906018CM	0010			
				4B0906018DA	4B0906018DQ	0060			
				4B0906018DN					
				4B0906018DP					
				4B0906018DQ					
				4B0906018Q	4B0906018Q	0009			
4B0906018P	4B0906018P	0009							
2000-2001	B5 Passat	2.8L ATQ	P0420	3B0907551AN	3B0907551AN	0050		01-07-07	8D0 906 961 A SVM 34DB
				3B0907551G	3B0907551G	0050			8D0 906 961 B SVM 34DC
				3B0907551BA	3B0907551BA	0050			8D0 906 961 D SVM 34DD
2004	B5 Passat	2.8L ATQ	Harsh 3-2 downshift	3B0 927 156 BA	3B0 927 156 BA	2225		01-07-18	W42PASSATSHIFT SVM 3534
				3B0 927 156 AT	3B0 927 156 AT				
2002 - 2003	B5 Passat	4.0 BDP	P0456 (Flashes ECM and TCM)	07D906018E	07D906018E	5088		01-07-38	W42W8UPDATECD SVM 34E0
				3B0927156T	3B0927156T	2222			
2004-2005	Beetle	1.9L BEW	Hard start or no start at or below 0°C (32°F) and/or runs rough after 28F6 Campaign	038906016P	038997016S	0283	28-10-05	3456	
	038906016J								
	038906016M								
	038906016Q			038997016R	0282				
	038906016H								
	Golf Jetta								
	Passat	2.0L BHW		038906016L	038997016T	0314			
		038906016R							
		038997016N							

A5 Golf Jetta B6 Passat								
Model Year	Model	Engine	Concern	Module Part #	New Part #	Level	Bulletin #	
2006-2008	A5 GTI A5 Jetta Eos B6 Passat	2.0L BPY	P0601 or P0642, P2004, P2008, P3137, P3138	1K0907115B	1K0907115B	0040	24M2 RVU 01-09-18 301D will update ECM and TCM	
				1K0907115H	1K0907115H	0040		
				1Q0907115B	1Q0907115E	0020		
				1Q0907115D		0020		
				1Q0907115E		0020		
				3C0907115F		0030		
				3C0907115G	3C0907115G	0030		
				3C0907115P	3C0907115P	0020		
				3C0907115S	3C0907115S	0020		
				09G927750FP	09G927750HJ	1068		
				09G927750CJ	09G927750HJ	1068		
		09G	Various shifting concerns				300B will update TCM only	
2007-2008	Jetta Passat	2.0L BPY	ECM/TCM Software Update and Valve Body Replacement for Harsh Up - Down Shift from Transmission when Cold	3C0907115P	3C0907115S	0020	01 11 30 320A	
				3C0907115S		0020		
				09G927750FP	09G927750C	1616		
				09G927750HJ		1617		
				09G927750FL	09G927750D	1649		
				09G927750D		1649		
				09G927750HE	09G927750E	1615		
				2006-2007	B6 Passat B6 Passat Wagon	3.6L		Mil and/or Oil pressure light comes on
03H906032C	03H997033N	2371						
09G Trans		09G927750AJ	09G927750HK			1271		
		09G927750FR						
		09G927750HK						

A5 Golf Jetta B6 Passat Continued											
Model Year	Model	Engine	Concern	Module Part #	New Part #	Updated Software	Technical	SVM or Disc			
2007	A5 Jetta A5 Rabbit	2.5L BGP 2.5L BGQ	P0011, P000A, or Exhaust noise on cold start	07K906032Q	07K906032Q	9650	01-07-57	W420607A5SWU SVM 34FC			
				07K906032R	07K906032R	9651					
				07K906032S	07K906032S	9652					
				07K906032T	07K906032T	9653					
				07K906032AA	07K906032AA	9654					
2007	Beetle	2.5L BPR 2.5L BPS		07K906032AB	07K906032AB	9655					
				07K906032AC	07K906032AC	9656					
				07K906032AD	07K906032AD	9657					
2006	A5 Jetta	2.5L BGP 2.5L BGQ		07K906032L	07K906032AN	9683					
				07K906032M	07K906032AP	9684					
				07K906032N	07K906032AQ	9685					
				07K906032P	07K906032AR	9686					
				07K906032	07K906032AS	9687					
2006	Beetle	2.5L BPR 2.5L BPS		07K906032A	07K906032AT	9688					
				07K906032B	07K906032BA	9689					
				07K906032C	07K906032BB	9690					
				09G927750AS 09G927750EL	09G927750ASGJ	0833					
2005	A5 Jetta	2.5L BGP BGQ		P3081 and Noise after Starting Cold	06A906032QC	06A906032QC			9422	01 11 04	348F
					06A906032QD	06A906032QD			9423		
			06A906032QE		06A906032QE	9424					
			06A906032QF		06A906032QF	9425					
			09G927750AS		09G927750AS	1205					
2009-2010	A5 Jetta A5 Rabbit	2.5L CBUA	DTC P0145 stored in ECM Fault Memory	07K906055AG	07K906055AG	9750	01 12 21 2028037	3565			
				07K906055AF	07K906055AF	9751					
				07K906055M	07K906055M	9752					
				07K906055N	07K906055N	9753					

A5 Golf Jetta B6 Passat Continued								
Model Year	Model	Engine	Concern	Module Part #	New Part #	Updated Software	Technical	SVM or Disc
2009-2010	A5 Jetta A5 Rabbit	2.5L CBTA CBUA	Engine Difficult to Start in Temperatures Below 32 degrees F (0 degrees C)	07K906055AG	07K906055AG	9970	01 12 22 2030305	3565
				07K906055AF	07K906055AF	9970		
				07K906055M	07K906055M	9970		
				07K906055N	07K906055N	9970		
				07K906055AJ	07K906055AJ	9970		
				07K906055AH	07K906055AH	9970		
				07K906055Q	07K906055Q	9970		
				07K906055P	07K906055P	9970		
2009	A5 Jetta A5 Rabbit	2.5L CBUA 2.5L CBTA	P150A	07K906055M	07K906055M	9970	01 13 29 2022598	3565
				07K906055N	07K906055N	9970		
				07K906055P	07K906055P	9970		
				07K906055Q	07K906055Q	9970		
2009	A5 Jetta A5 Rabbit	2.5L CBUA 2.5L CBTA	A/C cooling efficiency	07K906055M	07K906055M	9970	01 13 34 2018902	3565
				07K906055N	07K906055N	9970		
				07K906055P	07K906055P	9970		
				07K906055Q	07K906055Q	9970		

A6 Golf EOS Passat CC Tiguan						
Model Year	Model	Engine	Concern	Module Part #	New Part #	Level
2011-2013	CC	2.0T TSI	24AX High Pressure Pump Software	06J906027F	06J997029H	1513
				06J906027G	06J997029L	1516
				06J906027CK	06J997029F	1511
				06J906027CL	06J997029G	1512
				06J906027DC	06J997029J	1514
				06J906027FD		
	06J906027DD			06J997029K	1515	
	06J906027FE					
	Jetta			06J906027J	06J997029D	1509
				06J906027K	06J997029E	1510
				06J906027FH	06J997029B	1507
				06J906027FJ	06J997029C	1508
	Tiguan			06J906027Q	06J997029M	1517
				06J997027J		
				06J906027R	06J997029R	1521
				06J997027P		
				06J906027BE	06J997029M	1517
				06J997027K		
	06J906027BG			06J997029N	1518	
	06J906027FB					
	06J997027M					
	06J906027BH					
	Beetle			06J906027FC	06J997029P	1519
				06J997027R		
06J906027AE		06J997028J	1495			
06J906027AG		06J997028K	1496			
06J906027CD		06J997028P	1500			
06J906027FK						
	06J906027CE	06J997028N	1499			
	06J906027FL					

A6 Golf EOS Passat CC Tiguan										
Model Year	Model	Engine	Concern	Module Part #	New Part #	Updated Software Level	Technical Bulletin #			
2011-2013	EOS	2.0T TSI	24AX High Pressure Pump Software	06J906027AR	06J997028Q	1501	24AX			
				06J906027AS	06J997028R	1502				
				06J906027CH	06J997028S	1503				
				06J906027CJ	06J997028T	1504				
				06J906027FF	06J997029	1505				
				06J906027FG	06J997029A	1506				
	Golf/GTI			1K0907115AP	1K0907115AS	1K0907115AS		0040		
				1K0907115AS						
				1K0907115AQ					1K0907115AT	0040
				1K0907115AT						
2007-2008	Eos	3.2L BUB CBRA	DTCs P0420 and P0430 Stored in ECM Fault Memory	022906032CF	022906032CF	9971	01 11 10 2026254			
				022906032LF	022906032LF	9189				
				022906032KR	022906032KR	1319				
2008-2012	Tiguan, CC, Passat	2.0T CCTA CBFA	P150A Stored in ECM Fault Memory	06J906026F	06J906026F	4296	01 12 11 2018467			
				06J906026G	06J906026G	4297				
				06J906026H	06J906026H	4298				
				06J906026AF	06J906026AF	4060				
				06J906026AG	06J906026AG	4061				
				06J906026BR	06J906026BR	4063				
				06J906026BJ	06J906026BJ	4062				
							306A			
							3550			

A6 Golf EOS Passat CC Tiguan							
Model Year	Model	Engine	Concern	Module Part #	New Part #	Updated Software Level	Technical Bulletin #
2011-2012	Eos, CC	2.0T CBFA	DTC P050A and High Idle Faults Stored in ECM Fault Memory	06J906027AA	06J906027AA	9654	01 11 21 2027882
				06J906027CH	06J906027CH	1440	
				06J906027AR			
				06J906027AC	06J906027AC	9655	
				06J906027G	06J906027CK	0894	
2010-2013	Passat CC	2.0T CCTA CBFA	Poor Throttle Response	06J906027AB	06J906027AB	7506	24X8 01 12 27 2030838
				06J906027AC	06J906027AC	9971	
				06J906027F	06J906027FE	5369	
				06J906027G	06J906027FD	5368	
				02E300058N	02E300058N	3509	
2010	B6 Passat CC Eos Tiguan	2.0L CCTA 2.0L CBFA	Coolant Pump Activation	06J906021	06J906021	6992	24R9YR Update 24-10-04 3356
				06J906021C	06J906021C	6993	
				06J906021DA	06J906021DA	6987	
				06J906021DP	06J906021DP	6988	
				06J906021DN	06J906021DN	6989	
				06J906021DR	06J906021DR	6990	
				06J906021B	06J906021B	6991	
				06J906021DQ	06J906021DQ	6995	

A6 Golf EOS Passat CC Tiguan Continued									
Model Year	Model	Engine	Concern	Module Part #	New Part #	Updated Software Level	Technical Bulletin #	SVM or Disc	
2010-2013	Tiguan	2.0L	Fuel Pump Software Update	06J906026F	06J906026F	8216	24AV	3733	
				06J997026K					
				06J906026G	06J906026G	8217			
				06J997026L					
				06J906026H	06J906026H	8218			
				06J997026M					
				06J906027Q	06J906027Q	9972			
				06J997027J					
				06J906027BE	06J906027BE	9972			
				06J997027K					
				06J906027R	06J906027R	9972			
				06J997027P					
				06J906027FB	06J906027FB	8221			
				06J906027BG					
				06J997027M					
				06J906027BH	06J906027FC	8222			
				06J906027FC					
				06J997027R					
				06J906027GM	06J906027GM	8223			
				06J997027N					
				06J906027GN	06J906027GN	8224			
				06J997027S					
				06J906027HD	06J906027HD	8225			
				06J906027HE	06J906027HE	8226			
				06J906026DP	06J906026DP	8220			
				06J997026J					
				06J906026DN	06J906026DN	8219			
				06J997026H					

A6 Jetta B7 Passat New Edition Beetle						
Model Year	Model	Engine	Concern	Module Part #	New Module Part #	Updated Software Level
2011-2013	Jetta Golf Passat Beetle	2.5L CBTA CBUA	P0106 P0507 P050A	07K906055DA	07K906055DA	5691
				07K906055BE		
				07K906055CT	07K906055CT	5692
				07K906055BD		
				07K906055CL	07K906055CL	5860
				07K906055CK	07K906055CK	5861
				07K906055DH	07K906055DH	5689
				07K906055BC		
				07K906055DG	07K906055DG	5690
				07K906055BB		
				07K906055CQ	07K906055CQ	5854
				07K906055DB	07K906055DB	5855
				07K906055E	07K906055E	5858
				07K906055D	07K906055D	5859
				07K906055DF	07K906055DF	5687
				07K906055C		
				07K906055DE	07K906055DE	5688
				07K906055B		
				07K906055CP	07K906055CP	5872
				07K906055G		
				07K906055CN	07K906055CN	5873
				07K906055F		
				07K906055CJ	07K906055CJ	6448
				07K906055CH	07K906055CH	5863
				07K906055DJ	07K906055DJ	5684
				07K906055		
				07K906055DK	07K906055DK	5683
				07K906055A		
				07K906055CR	07K906055CR	5852
				07K906055CS	07K906055CS	5853
				07K906055DD	07K906055DD	5685
				07K906055AN		
				07K906055AM	07K906055DC	5686
				07K906055DC		
				07K906055AL	07K906055AL	5856
				07K906055AK	07K906055AK	5857

A6 Jetta B7 Passat New Edition Beetle Continued						
Model Year	Model	Engine	Concern	Module Part #	New Module Part #	Updated Software
						Level
2011-2013	Jetta Golf Passat Beetle	2.5L CBTA CBUA	Harsh Bump Stop	07K906055DA	07K906055DA	5691
				07K906055BE		
				07K906055CT	07K906055CT	5692
				07K906055BD		
				07K906055CL	07K906055CL	5860
				07K906055CK	07K906055CK	5861
				07K906055DH	07K906055DH	5689
				07K906055BC		
				07K906055DG	07K906055DG	5690
				07K906055BB		
				07K906055CQ	07K906055CQ	5854
				07K906055DB	07K906055DB	5855
				07K906055E	07K906055E	5858
				07K906055D	07K906055D	5859
				07K906055DF	07K906055DF	5687
				07K906055C		
				07K906055DE	07K906055DE	5688
				07K906055B		
				07K906055CP	07K906055CP	5872
				07K906055G		
				07K906055CN	07K906055CN	5873
				07K906055F		
				07K906055CJ	07K906055CJ	6448
				07K906055CH	07K906055CH	5863
				07K906055DK	07K906055DK	4733
				07K906055DJ	07K906055DJ	5684
				07K906055		
				07K906055A	07K906055DK	5683
				07K906055CR	07K906055CR	5852
				07K906055CS	07K906055CS	5853
				07K906055DD	07K906055DD	5685
				07K906055AN		
				07K906055AM	07K906055DC	5686
				07K906055DC		
				07K906055AL	07K906055AL	5856
				07K906055AK	07K906055AK	5857
			</			

A6 Jetta B7 Passat New Edition Beetle Continued

Model Year	Model	Engine	Concern	Module Part #	New Module Part #	Updated Software Level	Technical Bulletin #	SVM Unit
2013	Jetta	1.4L CNLA	P0087 P119A P164B P30A1	04E906023	04E906023	5631	01 13 15	384C
				5C0907080C	5C0907080C	0535	2033979	
2013-2014	Jetta	1.4L CNLA	ECM, Electric Drive and Battery Manager Update for Sporadic Misfire	04E906023	04E906023	6808	01 13 38 2034844	384C
				04E906023G	04E906023G	6807		
				5C0907080C	5C0907080E	0535		
				5C0907080D				
				5C0907080E				
5C6915182B	5C6915182B	0601						
2013-2014	Jetta	1.4L CNLA	fault 00332 or Fuel door will not open	04E906023	04E906023	6808->7928	01 14 02 2033454	384C
				04E906023G	04E906023G	6807		
				5C0907080C	5C0907080E	0535		
				5C0907080D				
				5C0907080E				
5C6915182B	5C6915182B	0601						
2012	Jetta Golf Beetle	2.5L CBTA CBUA	Poor throttle response concern	07K906055A	07K906055A	9740	01 12 15 2029373	3723
				07K906055CJ	07K906055CJ	3691		
				07K906055BC	07K906055BC	9738		
				07K906055CL	07K906055CL	3692		
				07K906055C	07K906055C	3116		
07K906055E	07K906055E	3689						
2011-2012	Jetta Golf	2.5L CBUA CBTA	Harsh Engagement from Park to Drive or Reverse	09G927750LH	09G927750LH	1916	01 11 15 2026944	3548
				09G927750LM	09G927750LM	1919		
				09G927750LF	09G927750LF	1914		
				07K906055BE	07K906055BE	8761		
				07K906055BC	07K906055BC	8759		
07K906055A	07K906055A	8755						
07K906055G	07K906055G	8757						

A6 Jetta B7 Passat New Edition Beetle Continued								
Model Year	Model	Engine	Concern	Module Part #	New Module Part #	Updated Software Level	Technical Bulletin #	
2013-2014	Jetta Beetle	CPLA CPPA	O2 Sensor DTC P2414 and/or P2237 along with O2 Sensor Replacement	06K906070T	06K906070T	8093	01 15 07 2038575	
				06K906070				
				06K906070AA	06K906070AA	8098		
				06K906070A				
2013-2015	Beetle, Jetta Passat, Golf	2.0T CPPA CPLA 1.8T CPKA CPRA	P0491 and or P2440	06K906071T	06K906071T	8451	3C8D	
				06K906071AA	06K906071AA	8347		
				06K906071AB	06K906071AB	8445		
				06K906071AC	06K906071AC	8446		
				06K906071N	06K906071N	8449		
				06K906071P	06K906071P	8450		
				06K906071B	06K906071B	8443		
				06K906071C	06K906071C	8444		
				06K906071J	06K906071J	8447		
				06K906071K	06K906071K	8448		
				06K906071D	06K906071D	9012	01-15-14 2040822	
				06K906071				
				06K906071E	06K906071E	9013	39D5	
				06K906071A				
				06K906070AC		8097		
				06K906070H	06K906070AC			
				06K906070C				
				06K906070AB		8092		
				06K906070C	06K906070AB			
				06K906070B				
				06K906070J	06K906070J	8054	3C07	
				06K906070M				
				06K906070F	06K906070F	8052		
				06K906070K				
2012	Passat	3.6L	P0420 P0430	03H906023E	03H906023BF	9259	01 16 11 2044303	
				03H906023BF	03H906023BF			

A6 Jetta B7 Passat New Edition Beetle Continued									
Model Year	Model	Engine	Concern	Module Part #	New Module Part #	Updated Software Level	Technical Bulletin #	SVM Unit	
2016-2017	Golf Sportwagen	1.8T	P039B, P03A5, P03AF, P03B9	8V0906264F	8V0906264K	0003	01-16-26 2045925	3EB1	
				8V0906264K					
eGOLF									
Model Year	Model	Engine	Concern	Module Part #	New Module Part #	Updated Software Level	Technical Bulletin #	SVM Unit	
2015-2016	eGOLF	N/A	High-Voltage Charger (C6) B200000 P31EA P168F	5QE915681B	5QE915681B	1560	93-16-02 2041920	3D13	
2015	eGOLF	N/A	High Voltage Battery Not Charging as Expected for Departure Time Set With Car-Net™	See TB			93-15-04 2040470	See TB	
2015-2017	eGOLF	N/A	Climatronic w/ Heat Pump	5GE907458	5GE907458A	0202	87-16-10 2040184	3C58	

A6 Jetta 1.4T							
Model Year	Model	Engine	Concern	Module Part #	New Module Part #	Updated Software Level	Technical Bulletin #
2016-2017	Jetta	1.4T CZTA	Misfires P0300 P0301 P0302 P0303 P0304	04E906023AK	04E906023AK	3670	01-16-24 2045602
				04E906023AP			
				04E906023N			
				04E906023AL	04E906023AL	3669	
				04E906023AQ			
				04E906023P			
2016-2017	Jetta	1.4T CZTA	P3081	04E906023AK	04E906023AK	3670	01-16-23 2045384
				04E906023AP			
				04E906023N			
				04E906023AL	04E906023AL	3669	
				04E906023AQ			
				04E906023P			
2016-2017	Jetta	1.4T CZTA	P0556	04E906023AK	04E906023AK	3670	01-16-22 2045383
				04E906023AP			
				04E906023N			
				04E906023AL	04E906023AL	3669	
				04E906023AQ			
				04E906023P			
2016-2017	Jetta	1.4T CZTA	P0456	04E906023AK	04E906023AK	3670	01-16-21 2045381
				04E906023AP			
				04E906023N			
				04E906023AL	04E906023AL	3669	
				04E906023AQ			
				04E906023P			
				SVM Unit			
				3D63			
				3D63			
				3D63			
				3D63			
				3D63			

Touareg continued									
Model Year	Model	Engine	Concern	Module Part #	New Module Part #	Updated Software Level	Technical Bulletin #	SYM Unit	
2006-2007	Touareg	5.0L (TDI) BWF	Low load vibrations	070906016AE	070906016CQ	9805	01-09-08 2019021		3004
				070906016BG					
				070906016BJ					
				070906016CQ					
2007	Touareg	4.2L BAR	P0601	7L0910560F	7L0910560F	0020	01-10-14 2024504		3107
2011-2012	Touareg	3.6L CGRA	Improve Cold Start - Rough Idle Concern	03H906023B	03H906023B	8688	01 13 31		35F4
				03H906023AG	03H906023AG	2580	2027780		36CE
2013-2014	Touareg	3.6L CGRA	P2181	03H906023BC	03H906023CD	7534	01 14 10		36CE
				03H906023CD	03H906023CD	7534	2036503		

Touareg							
Model Year	Model	Engine	Concern	Module Part #	New Module Part #	Updated Software Level	Technical Bulletin #
2004	Touareg	3.2L BAA	P0420 or P0430 Cold start misfires P0300-P0306	022906032BF	022906032BF	9779	01-08-11 2015134
2004	Touareg	4.2L AXQ	V8 poor throttle response	4D0907560DA	4D0907560DA	0050	01-05-04
2004-2006	Touareg	ALL	Drivetrain Binding/Tires Scrubbing During Low Speed Maneuvering ESP Light ON or Flashing	0AD927755L	0AD927755BE	0122	01 11 29 2011930
				0AD927755R			
				0AD927755AT			
				0AD927755AR			
				0AD927755AL			
2005-2006	Touareg	3.2L BMX	P0420 or P0430 Cold start misfires P0300-	0AD927755AJ	022906032GT	9911	01-08-13 2017410
				0AD927755AB			
2006	Touareg	4.2L AXQ	A/C not blowing cold	4D0907560DF	4D0907560DF	0030	01-07-53 2015019
2006-2007	Touareg	3.6L 09D Trans	Mil and/or Oil pressure light comes on	03H906032AG	03H997033R	2374	24L8/O2 Update 01-08-19
				03H906032D	03H997033P	2372	
				09D927750FF	09D927750FF	1274	
				09D927750CP	09D927750CP	1273	
2007-2009	Touareg	3.6L	Mil on P0420 P0430	03H906032AG	03H906032AG	6651	01-14-20 2037740
				03H906032S	03H906032S	7873	
				03H906032CB	03H906032ED	7874	
				03H906032ED			

Routan							
Model Year	Model	Engine	Concern	Module Part #	New Module Part #	Updated Software Level	Technical Bulletin #
2012	Routan	All	RHR Navigation Map Enhancements			HRT3 N 1108 4.3.0	91 13 21
SVM Unit CD Part number: RHRNAV/SW431							
2011-2012	Routan	All	RHR Radio Software	VIN Range 2V4__DG_BR640622 To 2C4__DG_CR425164		2.126	91K3 RVU
CD Part number: ROSWRHRTB2031926							
2014	Routan	3.6L CJUA	P0606	68206611AD	68206611AE		24S3 RVU '01 13 32
WiTech							
2010	Routan	4.0L CGVA	P050D (UNSOLD VEHICLES)	VIN Range DX_AR000001 To DX_AR209424			24I3/YK RVU 24-10-01
WiTech							
2010	Routan	4.0L CGVA	P050D	VIN Range DX_AR000001 To DX_AR209424			01-10-03
WiTech							
2010	Routan	3.8L	P013A (UNSOLD VEHICLES)	All			24S3/YQ
WiTech							
2009-2010	Routan	3.8L CGUA	P013A	VIN Range 41_9R000001 To D1_AR195846			01-10-02
WiTech							
2009	Routan	3.8L CGUA	Reprogram Oil change indicator system	All			17D4/Y7 RVU 24-09-01
WiTech							
2009	Routan	4.0L CGVA	Reprogram PCM for Thrust bearing	All			37E9/YB RVU 01-09-17
WiTech							
2009	Routan	All	P2181	All			01-10-12
WiTech							
2009-2014	Routan	All	Discharged Battery with Power Folding 3rd Row Seat	All			27-14-01
WiTech							

Transmission Control Module Updates							
Model Year	Model	Engine	Concern	Module Part #	New Module Part #	Updated Software Level	Technical Bulletin #
2012	Jetta, Passat, Beetle, CC, Tiguan, Golf	2.5L CBUA CBTA 2.0T CCTA 3.6L CNNA	Fault Code 00266 Stored in TCM will only flash certain Software Levels	09G927750HG	09G927750HG	2038->2172	01 12 34 2029268
				09G927750JE	09G927750JE	2034->2169	
				09G927750MH	09G927750MH	2061->2195	
				09G927750LM	09G927750LM	2044->2178	
				09G927750LR	09G927750LR	2062->2196	
				09G927750LE	09G927750LE	2040->2174	
				09G927750LF	09G927750LF	2041->2175	
				09G927750LG	09G927750LG	2042->2176	
				09G927750LH	09G927750LH	2043->2177	
2012	Tiguan	2.0L CCTA	Poor throttle response and or Driving Noise at Low Speeds in High Gear	09G927750LR	09G927750NK	2253 2248	01 12 13 2029206
2009	Tiguan	2.0L CCTA	Harsh 3-2 down shift when cold	09G927750GG	09G927750GG	1702	01 11 16 2022260
				09G927750KM	09G927750KM	1703	
				09G927750KN	09G927750KN	1704	
2008	A5 Jetta A5 GTI	2.0L BPY	Harsh 1-2 or 2-3 up shift	1K0907115S	1K0907115S	0040	01-09-14 2020922
				02E300044J	02E300044J	1416	
2007	A5 Jetta/GTI	2.0L BPY	Launch Control Program	02E325025AD	02E325025AD	1158	37-07-09 2013260
							W42DQ250RD2 SYM 3601

Transmission Control Module Continued									
Model Year	Model	Engine	Concern	Module Part #	New Module Part #	Level	Bulletin #	SVM Unit	
2007-2008	B6 Passat	2.0L BPY	ECM, TCM Software Update and Valve Body Replacement for Harsh Up - Down Shift from Transmission when Cold	3C0907115P	3C0907115S	0020	01-13-37 2012810	320A	
				3C0907115S		0020			
				09G927750FP	09G927750C	1616			
				09G927750HJ		1617			
	A5 Jetta	2.5L		09G927750FL	09G927750D	1649			
				09G997750D		1649			
				09G927750HE	09G927750	1615			
2006-2007	B6 Passat	2.0L BPY	Harsh Downshift after Extended Highway Driving	09G927750FP	09G927750FP	1199	01 11 31 2016941	300B	
				09G927750CJ	09G927750CJ	1135			
2006	B6 Passat	2.0L BPY	Harsh 5-4 downshift	09G927750CJ	09G927750CJ	1135	01-09-15 2012810	300B	
1999-2002	A4 Golf/Jetta	2.8L AFP	Automatic transmission, slips when shifting from 2nd to 3rd gear	01M927733MP	01M927733MP	5060	37-07-05	Replace TCM	
				01M927733DJ					
				01M927733JS					
				01M927733KR					
				01M927733MB					
				01M927733MH					

Radio / Navigation							
Model Year	Model	Engine	Concern	Module Part #	New Module Part #	Updated Software Level	Technical Bulletin #
2016	A6 Golf GTI eGolf Sportwagon Golf R	All	MIB2 Discover Media Composition Media Technisat Radios	See TB		0245	91-15-15 2042718
							SD Card SW0245TSUD
							SD Card
2016	All	All	MIB2 Discover Media Composition Media Delphi Radios	See TB		0245	91-15-14 2042343
2015	eGOLF		MIB1 MDI Connected Device Will Not Play or No Audio coding change	See TB			91-16-02 2043066
2015	A6 Golf/GTI	All	Radio switches to 87.7 EXCEPT eGOLF	See TB		P4430	91-15-07 2039352
							SW877UDWITHNAV SW877UDNONAV
2015	eGOLF		Display Shows Fuel Pump Icon after J794 Module Replacement	See TB		E5140	91-16-05 2040330
2014 2015	Passat CC Beetle	All	RNS 510 Welcome Screen shifted or distorted	See TB		5382	91-15-03 2037873
							Update CD K00 5001 68 99

Radio / Navigation							
Model Year	Model	Engine	Concern	Module Part #	New Module Part #	Updated Software Level	Technical Bulletin #
2014 2015	CC Eos Jetta□ Passat Tiguan	All	Premium 8 Radio Update	See TB		0010	91-15-08 2041770
2014	CC Eos Golf/GTI Jetta□ Passat Tiguan	All	UMI Software update Various Bluetooth Concerns	See TB	USB and SVM flash	0592	91-15-02 2036310
2013-2014	Jetta	1.4L	Stationary Vehicle Displayed While in Motion (Premium 8 Radio) Hybrid Only	see TB		0011	91-14-12 2038293
2012-2013	CC Beetle Eos Golf/GTI Jetta□ Passat Tiguan	All	Bluetooth audio runs in mono, Media player automatically starts when phone is connected, Bluetooth audio level is too high (Premium 8 Radio)	1K0035180AE	1K0035180AE	0008	91-14-09 2031136
				1K0035180T	1K0035180T		
				1K0035188D	1K0035188D		
				1K0035188E	1K0035188E		
				1K0035180AF	1K0035180AF		
				1K0035180AG	1K0035180AG	0008	383F (2012 model year)
				1K0035188F	1K0035188F		
				1K0035188G	1K0035188G		
				5C6035180	5C6035180		
				5C6035180A	5C6035180A	0009	37DC (2013 model year)

Radio / Navigation Continued									
									NAV DVD Part number
	CC								
2013-2014	Beetle	All	Radio, RNS 315 Radio Reboots, Radio Locks Out or Radio Switches Off at Random	See TB				0329	91-14-03 2036481
	Eos								
	Golf/GTI								
	Jetta								
	Passat								RNS315SW0417
	Tiguan							0417	
									RNS315SW0329
2010	CC	All	Radio, RCD510 (Premium 8)	See TB				0043	91-13-19 2023500
	Eos Golf/GTI Jetta Passat Tiguan								
									SD card RCD510SW0043
2009	A5 Jetta GTI	All	RNS 510 unable to load map data (U.S. only)	3C0 035 684 + index 7L6 035 684 + index				Map Data Only	91-10-22 2019935
	Eos Tiguan Passat & CC Touareg								
									RNS510SD2019935
2009	A5 Jetta	All	RNS 510 with various concerns	3C0 035 684 + index 7L6 035 684 + index				380/382	91-10-21 2019598
	A5 GTI Eos Tiguan B6 Passat								
									RNS510FLSH0380

Radio / Navigation Continued						
<u>Model Year</u>	<u>Model</u>	<u>Engine</u>	<u>Concern</u>	<u>Module Part #</u>	<u>Updated Software Level</u>	<u>Technical Bulletin #</u> <u>SVM Unit</u>
2005-2008	A5 Jetta B6 Passat Eos	All	Radio, navigation system, operating errors	1K0 035 197 + index	50	91-09-04 2016982 N/AVFLTAYSW50
2005-2008	A5 Jetta, B6 Passat GTI, Rabbit EOS	All	Premium 7 (6 disc changer, Panasonic Only) Corrects issues related to "amp clipping", reception issues, satellite radio inoperative, "bass flare", and radio does not power down when door open with key off	1K0 035 180 + index	35	91-09-06 2019894 PANFLSW0035 SVM 34A6
2008	Touareg 2	All	DVD navigation update, complaints of loss of presets in satellite radio mode	7L6 035 177 + index	30	91-08-02 2017408 N/AVFLASW30
2005-2007	Touareg	All	DVD navigation update	7L6 035 191 + (D/Q/S)	49	91-09-19 2015927 N/AVFLTOR49
2004-2005	Touareg	All	Complaints of battery drain and/or no start condition	7L6 035 191 + (A/B/D/E)	0635	91-09-01 2010556 W42TOURN/AV

Miscellaneous Control Units						
Model Year	Model	Engine	Complaint	Module Part #	Updated Software Level	Technical Bulletin # CD or SVM
2011	GTI Jetta Tiguan	All	Electronic Steering Column Lock w/ Kessy	5K0905861	120	28 11 01 96B7 3478
2010	Routan	90	Instrument cluster ambient temperature reading slow to react or inaccurate	N/A	N/A	90-10-06 2023618 Scan Tool ECU Flash
2010	Routan	97	TIPM Update	N/A	N/A	90F3/YJ RVU 97-10-01 Star MOBILE
2010	A6 Golf A6 GTI	97	Body Control Module Update	N/A	0576	97T2/YW RVU 97-10-08 33BC
2009-2010	Passat, CC	90	Update programming, gateway control module, incorrect message in multifunction display (MFD)	3C0907530J	0172	90-10-07 2023212 332B
				3C0907530K		
				3C0907530P		
				3C0907530L		
				3C0907530Q		
				3C0907530M		
2009	B6 Passat, Passat Wagon, CC	90	Software update for instrument cluster compass display	N/A	N/A	90-10-02 2022950 3176
				See TB		
2009	B6 Passat, CC	90	DTC 01317 Stored in instrument cluster control module -J285- or other control modules	3C0907530F SW 0142	0048	90-09-02 2020827 31D2

Miscellaneous Control Units Continued							
Model Year	Model	Engine	Complaint	Module Part #	Updated Software Level	Technical Bulletin #	CD or SVM
2008-2010	A5 Jetta A5 Rabbit GTI, R32 Eos Tiguan	90	Gateway control unit Update programming, Parking brake cannot be switched off, incorrect symbols in dash display	1K0907530L	1K0907530AD	91 11 20 2025606	328C
				1K0907530Q			
				1K0907530S			
				1K0907530AA			
				1K0907530AD	1K0907530AE		
				1K0907530N			
				1K0907530R			
				1K0907530T			
	1K0907530AB						
	1K0907530AE						
2005-2009	A5 Jetta A5 Rabbit GTI, R32 Eos Tiguan B6 Passat & CC	48	Steering system adaption Note: Applies to all steering rack replacements	N/A	See TB	48-09-01	W42RACKMAP50 SVM 337D
2005-2009	A5 Jetta A5 Rabbit GTI, R32 Eos Tiguan	91	Cruise control inoperative, DTC 18104 and/or DTC 18106 present Note: Unflashed vehicles will have a zero for the last digit of the software level	N/A		27-09-03	Scan tool test plan "Adaptation cruise control system debounce counter"
2005-2009	A5 Jetta A5 Rabbit GTI, R32 Eos Tiguan	91	Steering wheel menu change buttons inoperative	N/A	See TB	90-09-01	Scan tool test plan "Adaptation menu key multifunction steering wheel"
2004	Phaeton	90	Analog clock runs slow (Infotainment)	N/A		90-07-01	Call Helpline
2004	Phaeton	90	Instrument cluster display distortion	N/A		90-06-02	Call Helpline

Miscellaneous Control Units Continued						
Model Year	Model	Engine	Complaint	Module Part #	Updated Software Level	Technical Bulletin # CD or SVM
2004-2008	Beetle & Beetle Convertible A5 Jetta GTI, R32 B6 Passat	69	Airbag Pods system faults DTC 02511 014	N/A	See TB N/A	01-08-07 2010347 W42DTC02511014 - 2
2006-2007	B6 Passat	45	EPB update to prevent false DTC's: 00446 002, 00532 002, 02428 002, 0229 002, 02433 011, 02433 012	3C0907801B 3C0907801E	0001 3C0907801BZ	01-07-47 2084
2007	Eos	57	OS update TPMS and comfort module	N/A	See TB 0218	W42INSTKUPDATECD SVM 34A6 01-06-20
2008 - 2009	Touareg	90	Menu options missing from MFI	Multiple	See TB 9533	90-08-07 Multiple
2007-2009	Eos	91	Compass reads incorrectly (Non navigation vehicle)	1Q0919965	See TB 0002	91-09-25 COMPASFLASHSW002 SVM 34F8
2004	Touareg	90	Touareg clock loses time Read TB; Two Part Flash	7L6 920 980 M, N, P 7L6 920 970 L, M 7L6 920 870 M, N, P 7L6 920 880 L, M	See TB 2922 1822 2922 1822	W42TOURCLUSTER SVM 34DF 90-08-02
2000	A4 Golf A4 Jetta	90	VS campaign instrument cluster update	N/A	See TB N/A	VS VW18192804

Vehicle Updates						
Model Year	Model	Engine	Concern	Module Part #	New Part #	Updated Software Level
2011-2012	Touareg	3.0L CATA	P208C P208E P20EE P150A	7P0907401E 7P0907401J	7P0907401J	0003
						Technical Bulletin # 26 12 01 23K9
2010	Tiguan Passat CC EOS	CCTA CBFA	Coolant Pump Activation	06J906021 06J906021C 06J906026DA 06J906026DP 06J906026DN 06J906026DR 06J906021B 06J906021B 06J906026DQ	06J906021 06J906021C 06J906026DA 06J906026DP 06J906026DN 06J906026DR 06J906021B 06J906021B 06J906026DQ	6992 6993 6987 6988 6989 6990 6991 6995
						24 10 04 24R9
2012	Jetta Beetle Passat	2.0T CCTA CBFA 3.6L CDVB	to correctly store ECM scan tool mode data	06J906027J 06J906027K 06J906027AG 06J906027CE 06J906027AE 06J906027CD 03H906023E	06J906027J 06J906027K 06J906027AG 06J906027CE 06J906027AE 06J906027CD 03H906023E	2907 2908 2906 2904 2909 2905 3013
						24W1
						366D
2009-2011	Jetta Golf SportWagen	CBTA CBUA	Rough running behavior and cold start issues at certain conditions (under high electric power)	07K906055BE 07K906055BD 07K906055BC 07K906055BB 07K906055AG 07K906055AF 07K906055AJ 07K906055AH 07K906055M 07K906055N 07K906055P 07K906055Q 07K906055G 07K906055F 07K906055A 07K906055	07K906055BE 07K906055BD 07K906055BC 07K906055BB 07K906055AG 07K906055AF 07K906055AJ 07K906055AH 07K906055M 07K906055N 07K906055P 07K906055Q 07K906055G 07K906055F 07K906055A 07K906055	9213 9212 9210 9211 9970 9970 9970 9970 9970 9970 9970 9970 9217 9216 9214 9215
						24 10 04 24W4
						3565
2010	Touareg	3.6L BHK	Catalyst Monitoring	03H906032GQ	03H906032GQ	9893
						24 12 05 24X5
						35B1

Vehicle Updates Continued										
Model Year	Model	Engine	Concern	Module Part #	New Part #	Updated Software Level	Technical Bulletin #	SVM Unit		
2011	Jetta	2.0L CBPA	Idle w A/C on and poor throttle response	06G906055T	06G906055T	1205	24X7	3801		
				06G906055R						
				06G906055B						
				06G906055AA	06G906055AA	1205				
				06G906055S						
				06G906055C						
				09G927750LE						
09G927750LE	09G927750LE	2330								
09G927750LE	09G927750LE	2329								
2011	Jetta	2.0L CBPA	Poor throttle response concern	06G906055T	06G906055T	1205	24Y4	3801		
				06G906055AA	06G906055AA	1205				
				09G927750LE	09G927750LE	1791->2330				
				09G927750LE	09G927750LE	1975->2330				
				09G927750LE	09G927750LE	2040->2329				
				09G927750LE	09G927750LE	2174->2329				
2013	Jetta	1.4L CNLA	optimizes Hybrid system operation	04E906023 5C0907080C	04E906023 5C0907080C	5631 0535	01 13 15 24Z5	384C		
2010-2012	Golf/GTI Jetta Eos CC Beetle	2.0T CJAA 2.0T CCTA CBFA	Customer states while braking and down shifting in Tiptronic mode the transmission does not respond accordingly. Customer states while accelerating from a rolling stop, the transmission does not respond accordingly.	02E300054M	02E300057B	2604->2730	37G2	364B		
				02E300054M		2609->2730				
				02E300057B		2714->2730				
				02E300057B		2720->2730				
				02E300054J	02E300057A	2605->2731				
				02E300054L		2715->2731				
				02E300057C		2721->2731				
				02E300057C		2601->2705				
				02E300057B	02E300057C	2602->2724				
				02E300054C		2605->2724				
				02E300058E		2717->2724				
				02E300057B		2720->2724				
				02E300054C	02E300057B	2714->2730				
				02E300058E		2720->2730				
				02E300054C		2802->2806				
				02E300058E		2803->2806				
				02E300058E	02E300058E	2801->2805				
				02E300058E		2804->2805				

Vehicle Updates Continued									
Model Year	Model	Engine	Concern	Module Part #	New Part #	Updated Software Level	Technical Bulletin #	SVM Unit	
2013	CC	2.0T CCTA CBFA	DSG Software update	02E300058N	02E300058N	3522	37H3	3733	
	Beetle					3523			
2012	Passat	All	Kessy Update	5K0959434A	5K0959434B	0802->0902	57E1	3639	
2013	Beetle Convertible	All	Convertible top update to improve top function see Bulletin for other model updates	5C3871601	5C3871601	0344	61B7	382F	
2011	Jetta	All	The A/C system might not cool the vehicle fast enough or Key to lose adaption	5C0820047H	5C0820047M	103	87C6	345F	
				5C0820047J	5C0820047N	103			
				5C0820047K	5C0820047P	103			
				5C0 820 047L	5C0 820 047Q	103			
2012	Tiguan Golf/GTI Sportwagen CC	All	Heater is not blowing hot enough	AC Module	See TB	0303->0404 0304->0404	87D3	36C8	
2013	Tiguan Golf/GTI Beetle Passat Jetta CC	All	Radio Update Premium 8 from sw level 0007 to 0008 only, see bulletin	1K0035180AF	1K0035180AF	0007->0008	91J7	SD Card	
2011	GTI Jetta Tiguan	All	Electronic Steering Column Lock w/ Kessy	5K0905861	5K0905861	120	28 11 01 96B7	3478	
2015	Passat	1.8T	37J2 Transmission update	09G927749B	09G927749B	2855	37J2	3B8B	
	Jetta			09G927749A	09G927749A	2856			
	Beetle			09G927749	09G927749	2857			
	Golf			09G927749D	09G927749D	2866			
2010-2013	Passat CC	2.0T CCTA CBFA	Poor Throttle Response	06J906027AB	06J906027AB	7506	24X8 01 12 27	3733	
				06J906027AC	06J906027AC	9971			
				06J906027F	06J906027FE	5369			
				06J906027G	06J906027FD	5368			
				02E300058N	02E300058N	3509			

Error Codes from Odis

ODS0001E

The sensor is not connected to the logical connection.

Please contact Support.

ODS0002E

Executing in current condition is not permitted.

Please contact Support.

ODS0003E Object is in poor condition. Please contact Support.

ODS0004E

The configuration does not match the connected device.

Please contact Support.

ODS0005E

An error occurred in the oscilloscope display module.

Please contact Support.

ODS0006E

A trigger channel was not established for the triggered measurement.

Please contact Support.

ODS0007E

The GDI versions of GDI components do not match.

Please contact Support.

ODS0008E A GDI error has occurred. Please contact Support.

ODS0009E

An error occurred in the GDI coordinator: ... (Error code: ...

Please contact Support.

ODS0010E

An error occurred in the GDI driver: ... (Error code: ...

Please contact Support.

ODS0011E A conflict with the DCD has occurred. Please contact Support.

ODS0012E

A failure occurred when installing the device driver.

Please contact Support.

ODS0013E

The measuring device is not established in the GDI driver.

Please contact Support.

ODS0014E

An error occurred when parsing the specified curve

Please contact Support.

ODS0501E

No knowledge base is available for the selected model.

The "Flashing" mode cannot be per

Please check if there are updates to the software or data.

If the problem persists, please contact support

formed for this model. immediately.

ODS0502E

The existing software installation is incomplete.

The "Flashing" mode cannot be performed with the existing software.

Please check if there are updates to the software or data.

If the problem persists, please contact support immediately.

ODS0503E

The current brand ... is not supported by the "Flashing" operating mode at this time.

The "Flashing" mode cannot be performed for this brand.

Please check if there are updates to the software or data.

If the problem persists, please contact support immediately.

ODS0504E

There are inconsistencies within the diagnostic data for the current brand

The "Flashing" mode cannot be performed for this brand.

Please check if there are updates to the software or data.

If the problem persists, please contact support immediately.

ODS0505E

There are ambiguities within the diagnostic data for the current brand

The "Flashing" mode cannot be performed for this brand.

Please check if there are updates to the software or data.

If the problem persists, please contact support immediately.

ODS1001E Not available - timeout after ... seconds. Please contact Support.

ODS1002E the session for account ... has expired.

Please restart the program.

If the problem persists, please contact support immediately.

ODS1003E

The connection to VehicleBaseServiceV15 could not be established.

Incorrect connection and server data have been entered in the administration area.

Please contact Support.

ODS1004E the connection to ... ended.

Please try again. If it is still not possible to login, contact Support.

ODS1005E

A transmission error ... occurred when connecting to

The connection was interrupted.

Please try again or contact Support.

ODS1006E

A connection could not be established with the URI/URL.

The address is not responding currently.

Please try again later or contact Support.

ODS1007E

Negative response from the server. The error ID is ...

Please contact Support.

ODS1008E Negative response from the server: Please contact Support.

ODS1501E

The version of the selected session ... is not compatible with the current program version

The session cannot be loaded.

Please contact Support.

ODS1502E

The type of the selected session ... is not compatible with the current product The session cannot be loaded.

Please contact Support.

ODS1503E

The type of selected session cannot be identified. The session cannot be loaded.

Please contact Support.

ODS2001E the password for account ... is invalid. Please contact Support.

ODS2002E the password for account ... has expired. Please contact Support.

ODS2003E No authentication available. Please contact Support.

ODS2004E the account ... is unknown. Please contact Support.

ODS2005E Authentication is required to access Please contact Support.

ODS2006E

The hardware with ID ... is marked as locked. Please contact support.

A login was attempted with a tester whose hardware ID was locked on the server side.

Please contact Support.

ODS2007E

Your flat rate has expired. Please obtain a new flat rate from erWin.

Please obtain a new flat rate if you are an independent market operator.

Please contact Support if you are an authorized dealer.

ODS2008E

The maximum number of simultaneous user's sessions for your flat rate has been reached. A login is only available once a current user session ends.

Please log in again later.

ODS2500E

The group system has reported an error: ...

Please contact Support.

ODS2501F

No MCD system was found. Please check the MCD system installation.

Please contact Support.

ODS2502E No data available. Probable causes are:

- Missing or faulty vehicle project
- No suitable MCD Server runtime data
- The control module is not designed for this function

ODS2503E The VIN could not be read or detected.

Make sure there is a connection to the vehicle and the ignition is switched on.

ODS2504F No MCD/DTS system was found. Please contact Support.

ODS2506E Printing could not be completed.

The printer could not be accessed

The user canceled the print job.

Please check the printer settings or contact the system administrator.

ODS2507E

The print layout for the graphic could not be generated.

Please contact Support.

ODS2508F

Important MCD server libraries were not found.

Probable causes are:

1. The MCD server is not installed. Please install the current MCD server to correct this.
2. The system path does not contain the MCD sever working directory.
3. The MCD server working director cannot be accessed.

Please contact Support.

ODS2509F There are differences between the installed and expected version of necessary

Please install the current MCD server to correct this.

Softing libraries. Please contact Support.

ODS2510F

The ECF framework for access to the MCD system could not be found.

Please install the current ECF version to correct this.

Please contact Support.

ODS2511F The MCD system could not be found.

There are several probable causes.

1. Another application that uses the MCD server is active. Close those applications and restart the application.

2. Another application that uses the MCD server cannot be closed. Restart the computer and try again.

Please contact Support.

ODS2512F

The system is powering down. All activities in progress will be ended.

Please check if Offboard Diagnostic Information System Service functions correctly after starting. If it does not function correctly, contact Support.

ODS2513E

The MCD system diagnostic interface is not configured clearly.

Check the configuration of your diagnostic hardware in the PDU API and modify if necessary.

ODS2514E

Error when accessing the Logical Link Monitor for the MCD system.

Please contact Support.

ODS2515E Error when opening the MCD project. Please contact Support.

ODS2520E

The help system is not complete.

Help information cannot be displayed.

Please contact Support.

ODS2521E

The help file ... in ... cannot be opened.

Help information cannot be displayed (...).

Make sure the help file is in specified location and there is read access to it or contact support.

ODS3001E the file ... was not found.

Make sure the correct path was entered or contact Support.

ODS3002E

Account ... does not have read authorization for the file ...

You do not have the necessary authorization. Please contact Support.

ODS3003E

Account ... does not have write authorization for the file ...

You do not have the necessary authorization. Please contact Support.

ODS3004E No space to write the file ...

The data storage location is full. Please contact your system administrator or Support.

ODS3005E the file folder ... was not found.

Make sure the correct path was entered or contact Support.

ODS3006E

Incorrect file name format for file ... The format ... was expected.

Please contact Support.

ODS3007E

The file ... in the folder ... cannot be written.

Please contact Support.

ODS3008E

The file ... in the folder ... cannot be opened or read.

Please contact Support.

ODS3009E the file ... cannot be copied to Please contact Support.

ODS3010E

Filter file for HexService is not available or cannot be read.

The HexService function cannot be performed.

Please contact Support.

ODS3011E

An error occurred when displaying the results of the equipment level check.

Please contact Support.

ODS3012E

An error occurred when generating the HTML results log.

Please contact Support.

ODS3013E

An error occurred during the Html transformation for the current vehicle project.

Please contact Support.

ODS3014E

An error occurred when unpacking the file.

Please contact Support.

ODS3015E

The selected data set does not contain a control file.

Please contact Support.

ODS3501E

Connection data to group systems incorrect or not available. Please contact support.

Please contact Support.

ODS4001E

The data structure ... could not be created or converted. Please contact support.

Please contact Support.

ODS4002E the software library ... was not found. Please contact Support.

ODS4003E

The software library ... could not be opened.

Please contact Support.

ID Displayed Error Note

ODS4004E

The parameters received for the request from ... are incorrect.

Please contact Support.

ODS4005F Incorrect Java installation. Please contact Support.

ODS4006E the service module ... is not available. Please contact Support.

ODS4007E the service ... could not be configured. Please contact Support.

ODS4008E

The session for vehicle ... could not be reestablished.

Please check the connection to the vehicle or contact Support.

ODS4009E

An internal system error has occurred. The system is unstable. Please send a feedback and contact support. End the system and restart.

Please restart the system. If the error is not corrected, contact Support.

ODS4010E

The file structure ... contains content errors.

Please contact Support.

ODS4011E the system does not support the code Please contact Support.

ODS4012E No session data available for saving. Please contact Support.

ODS4013E Session data cannot be reconstructed. Please contact Support.

ODS4014E Session data cannot be saved. Please contact Support.

ODS4015E

An error occurred when entering one of the parameters.

Please contact Support.

The entry cannot be converted into the parameter type.

ODS4016E

An error occurred when entering one of the parameters.

The parameter type is not supported.

Please contact Support.

ODS4501E

The road test mode could not be activated.

Please contact Support.

ODS4502E

The license file cannot be opened or read. Road test mode was not activated.

Please contact Support.

ODS4503E

The license file could not be copied. Road test mode was not activated.

Please contact Support.

ODS4504E

The road test mode could not be deactivated.

Please contact Support.

ODS5001E Test program/step ... cannot be loaded. Please contact Support.

ODS5002E

Measurement connection is not available.

Please contact Support.

ODS5003E

A fatal internal test program error has occurred. Test canceled. Error type: ...

Details: ...

Please contact Support.

ODS5004E

Internal test program error. A user action was attempted that is not permitted within a test step. Test canceled.

Please perform the test again or contact Support.

ODS5005E the document ... could not be loaded. Please contact Support.

ODS5006E

The knowledge bank for the vehicle could not be determined. Guided Fault Finding is not possible for this vehicle. Details: ...

Please contact Support.

ODS5007E

A version problem was detected with the ... test.

Please contact Support.

ODS5008E

Decompression of the ... test program failed due to missing or invalid compression. The test program could not load.

Please contact Support.

ODS5009E

Decryption of the ... test program failed due to missing or invalid encryption. The test program could not load.

Please contact Support.

ODS5010E

Signature validation of the ... test program failed due to a missing or manipulated signature. The test program could not load.

Please contact Support.

ODS5501E Control module ... could not be found. Please contact Support.

ODS5502E Connection ... could not be opened. Please contact Support.

ODS5503E Connection ... could not be established. Please contact Support.

ODS5504E

Unexpected result of control module communication, method ...

Please contact Support.

ODS5505E

Control module communication could not be performed, method ...

Please contact Support.

ODS5506E

Error ... during control module communication, job ..., control module ..., ECF error text: ...

Please contact Support.

ODS5507F

Communication descriptive file ... could not be found.

Please contact Support.

ODS5508F

Error when reading the communication descriptive file.

Please contact Support.

ODS5509F

Content of the communication descriptive file invalid.

Please contact Support.

ODS5510E

Communication job ... for control module ... could not be found in the descriptive file.

Please contact Support.

ODS5511E

Faulty description of method ... in the description file.

Please contact Support.

ODS5512E

Error when compiling parameters for class ...

Please contact Support.

ODS5513E

Communication job ... for connection ... could not be created.

Please contact Support.

ODS5514E

Fault job description for ... in descriptive file.

Please contact Support.

ODS5515E

Error when providing results of control module communication.

Please contact Support.

ODS5519E

Internal error in test program: Method ... for job ... not found.

Please contact Support.

ODS5551E

Connection name for control module ... could not be found.

Please contact Support.

ODS5552E

Communication job ... could not be established.

Please contact Support.

ODS5553E

Request parameters for communication job ... could not be established.

Please contact Support.

REFERENCE GUIDE MVB

Gasoline Engines

- 00 General Engine Data - Summary
- 01 Engine Idling Test
- 02 Engine Idle - MAF Sensor / Injection Timing
- 03 Engine Idle - Timing / Throttle
- 04 Engine Idle - Intake / Coolant Temperatures

- 05 Engine Functions - Idle Control / Operating Mode
- 06 Engine Functions - Fuel Trim
- 07 General Engine Data - BDE
- 08 General Engine Data
- 09 Oil Fill Level / Fuel Consumption
- 10 Ignition at Idle - Load / Timing
- 11 Ignition at Idle - Temperature / Timing
- 12 Distributor Adjustment
- 13 Injection Quantity Deviation (TDI Only)
- 14 Misfire Recognition - Total
- 15 Misfire Recognition - Cylinder 1-3
- 16 Misfire Recognition - Cylinder 4-6
- 17 Misfire Recognition - Cylinder 7-9
- 18 Misfire Detection Limits
- 19 Misfire Recognition - Cylinder 10-12
- 20 Timing Retard - Cylinder 1-4
- 021 Timing Retard - Cylinder 5-8
- 22 Timing Retard - Cylinder 1 & 2
- 23 Timing Retard - Cylinder 3 & 4
- 24 Timing Retard - Cylinder 5 & 6
- 25 Timing Retard - Cylinder 7 & 8
- 26 Knock Control - Cylinder 1-4
- 27 Knock Control - Cylinder 5-8
- 28 Knock Sensor Test
- 30 Lambda Control - Sensor Status
- 31 Lambda Control - Sensor Voltages
- 32 Lambda Control - Mixture Adaptation
- 33 Lambda Control - Summary
- 34 Lambda Control - Aging Check - Bank 1 / Bank 3 (Pre-Cat)
- 35 Lambda Control - Aging Check - Bank 2 / Bank 4 (Pre-Cat)
- 36 Lambda Control - Sensor Readiness - After Catalyst
- 37 Lambda Control - Delta Lambda - Bank 1
- 38 Lambda Control - Delta Lambda - Bank 2
- 39 Lambda Control - Sensor Exchange
- 40 Lambda Sensor Heating Resistor - Combined Wires / Heaters
- 41 Lambda Sensor Heating - Bank 1
- 42 Lambda Sensor Heating - Bank 2
- 43 Lambda Sensor Aging - Bank 1 (Post-Cat)
- 44 Lambda Sensor Aging - Bank 2 (Post-Cat)
- 45 NOx Memory Catalytic Conversion
- 46 Catalytic Conversion Test Bank 1
- 47 Catalytic Conversion Test Bank 2

- 48 Thermal Cat. Conversion Diagnosis - Bank 1
- 49 Thermal Cat. Conversion Diagnosis - Bank 2
- 50 Engine Speed Increase
- 51 Engine Speed Increase - Gear Shifts
- 52 Engine Speed Increase - RPM Regulation
- 53 Engine Speed Increase - Generator Load
- 54 Closed Throttle Position Switch
- 55 Idle Speed Stabilization

• REFERENCE GUIDE

- Measuring Value Blocks - Gasoline Engines
- 56 Idle Speed Stabilization
- 57 Idle Speed Stabilization - Air Condition
- 58 Engine Mounting
- 60 Electronic Throttle Body Adaptation
- 61 E-Gas Adaptation
- 62 Electronic Throttle
- 63 Electronic Throttle - Kick-Down Adaptation
- 64 Throttle Body Potentiometer Adaptation Values
- 65 Potentiometer Range / Status
- 66 Cruise Control System
- 67 Cruise Control Shut-Off
- 68 Transmission Range / Torque Conversion
- 69 Air / Ride Spring Status
- 70 Fuel Tank Venting / Valve Testing
- 71 Fuel Tank Leak Test
- 72 Fuel Tank Leak Test 2
- 73 Fuel Tank Venting / Mixture
- 74 EGR Regulator Solenoid Adaptation
- 75 EGR Short Trip
- 76 EGR Pressure Systems / Air Mass System
- 77 Test Secondary Air Injection System - Bank 1
- 78 Test Secondary Air Injection System - Bank 2
- 79 Exhaust Flap - Banks 1 & 2
- 80 Advanced Control Module Identification I (Manufacture Date)
- 81 Advanced Control Module Identification II (VIN & Immobilizer ID)
- 82 Advanced Control Module Identification III (Flash Data)
- 83 Advanced Control Module Identification III (First VIN)

- 85 Mileage / Ignition Cycle Count
- 86 Readiness Code I
- 87 Readiness Code II
- 88 Readiness Code III
- 89 Distance Driven with MIL On
- 90 Continuous Camshaft Adjustment - Bank 1 - Exhaust
- 91 Continuous Camshaft Adjustment - Bank 1 - Intake
- 92 Continuous Camshaft Adjustment - Bank 2 - Intake
- 93 Continuous Camshaft Adaption Values
- 94 Continuous Camshaft Adjustment - Banks 1 & 2 - Intake
- 95 Performance Increase - Intake Manifold Change Over
- 96 Continuous Camshaft Adjustment - Banks 1 & 2 - Exhaust
- 97 Performance Increase - Intake Air Change Over / Snow Flap
- 98 Continuous Camshaft Adjustment - Bank 2 - Exhaust
- 99 Lambda Control Shut-Off - Basic Setting
- 100 Readiness Code (Older Systems)
- 101 Fuel Injection
- 102 Fuel Injection
- 103 Air-Shrouded Fuel Injectors
- 104 Start Adaptation Values
- 105 Cylinder Shut-Off
- 106 Fuel Pump Status / Shut-Off Time
- 107 Lambda Regulation - Banks 1 & 2
- 110 Load / Full Throttle Enrichment
- 111 Boost Pressure Control
- 112 Exhaust Gas Temperature
- 113 Load / Full Throttle Enrichment - Last Check
- 114 Boost Pressure Control (%)
- 115 Boost Pressure Control (mBar)
- 116 Boost Pressure Control - Correction
- 117 Boost Pressure Control - Pedal Pos. / Throttle Angle
- 118 Boost Pressure Control - Temperature / Pressure
- 119 Boost Pressure Control - Control Valve Status
- 120 Traction Control - ASR / FDR
- 122 Transmission
- 123 Reserved For CAN-Bus Signals
- 124 Reserved For CAN-Bus Signals
- 125 CAN-Databus Powertrain Communication (Modules 02 / 03 / 17 / 08)
- 126 CAN-Databus Powertrain Communication (Modules 13 / 44 / 15 / 09)
- 127 CAN-Databus Powertrain Communication (Modules 22 / 34 / 16)
- 128 Reserved For CAN-Bus Signals
- 129 Reserved For CAN-Bus Signals

- 130 Map Cooling - Coolant Filling
- 131 Map Cooling - Temperatures
- 132 Map Cooling - Status
- 133 Coolant Fan Configuration
- 134 Temperatures
- 135 Coolant Fan Control
- 136 Relay for Coolant Fan Actuation
- 137 Air Condition Requirements
- 138 Air Mass - Average / Vehicle Speed
- 139 Air Mass - Actual / Specified
- 140 Pressure Control Valve
- 141 Fuel Supply System
- 142 Throttle Position Range / Status
- 143 Charge Movement Flap Opening / Status
- 144 Charge Movement Flap Actual / Specified
- 145 Exhaust Gas Temperature Sensor
- 146 Exhaust / Catalytic Converter Status
- 147 Charge Movement Flap For BDE
- 148 Catalytic Converter Status
- 160 Cylinder Recognition / Control - Cylinder 1-4
- 161 Cylinder Recognition / Control - Cylinder 5-8
- 162 Lambda Control - Delta Lambda - Specified / Actual
- 163 164 165
- 166 O2 Bank 1 Status
- 167 Deceleration Calculation / Thrust Count
- 168 Potentiometer Range / Status
- 169 Turbo Bypass / Status
- 170 Starter Voltage / Relay Status
- 171 Clutch Switch
- 199 Temperatures - Status (Cats/Coolant)
- 200 Readiness Code - Status
- 201 O2 Dwell / Range
- 204 Manifold Pressure 205
- 208 Throttle Opening 209
- 220 Ground Current
- 221 Coolant / Intake Temperature

Glossary

Amplitude

The maximum value that the amount of deflection of an oscillation in an alternating current (for example, in AC voltage) can reach.

Adaptation

This service enables interactive changing of parameters in the control system that is being addressed. The changed values (for example, correction values for idle speed) can be stored permanently in the control modules. The user has the option to change the value and to transfer it into the temporary memory (RAM) to check on the control module. The control module applies the new values to its outputs and the user can check the system's reaction. If the right correction value is found, the tester causes the control module to transfer the value and the workshop code into the writable hard drive (EEPROM).

In contrast to basic setting, the affected control circuit is closed. With the adaptation, system-specific parameters are determined and stored in the vehicle system.

ASAM-ODX

Association for Standardization of Automation and Measuring Systems (<http://www.asam.net>)

Open Diagnostic Data Exchange

Baseline

A complete version of a DIDB. It contains all required artifacts, tests programs and databases.

Operating Mode

Each of the tester's basic functions that can be accessed from the start screen: "Flashing", "Diagnosis", "Information" and "Admin". Each operating mode is divided into a range of individual functions.

Bluetooth

An industry standard for wireless transmission between devices over short distances.

Client

A program on the PC that enables the connection to a server. A network client is, for example, a program that establishes the connection to a server in the network so that the PC can be used as a work station in the network.

Collective term for functions, build groups or components that can be diagnosed and are represented in the diagnostic object tree. Not to be confused with diagnostic bus object (definition in DES-VW A11.0 owner's manual) An object (function, component or build group) on which the diagnostic function is used.

Diagnostic objects should be named based on the list. Even if this is not currently the case, it must be done in the future so that wiring diagrams on the tester can be requested according to list terms from Elsa.

Diagnostic Log

The diagnostic log contains a list of control modules with corresponding DTC memory entries, DISS codes and text created manually.

DIDB

Direct current measurement (inline current measurement)

Current measurement in which the tester is inserted directly into the circuit like an ampere meter. Opposite: inductive current measurement via a clamp connected to the cable.

DISS

The DISS system (Direct Information System Service) is used to record vehicle concerns and support the service core process.

- Recording concerns
- Reporting existing concerns

DTC

Diagnostic Trouble Code. An entry in the fault memory. It consists of the fault location, fault types and ambient conditions, if necessary.

ECU

Electronic Control Unit: electronic control module.

OBD

Vehicle systems are OBD-capable. This means they can continually check their own functions, connected sensors and actuators. A malfunction results in the entry of an error code in the vehicle system DTC memory. The tester contains all malfunctions in its knowledge base so that it can allocate the error code to an error type and location after reading the DTC memory and then create a test sample based on that.

Own test plan

Diagnostic strategy where the user selects possible faulty functions or components. If faults in the vehicle systems are detected during the diagnostic sessions or a concern is entered, the test plan always differentiates between the system test plan and the user's own test plan.

End module

An end module can consist of several function tests that start automatically when exiting Guided Fault Finding. For example, feedback may be sent to the vehicle manufacturer.

Incident code

Incident location

DTC memory

Rules of thumb

Logical relationship based on noticeable symptoms and/or symptoms from the fault memory model, among each other or with each other. A rule of thumb can be evaluated according to its reliability and assigned to one or more diagnostic objects.

eShop

eShop is the system for ordering and licensing software and diagnostic data within the Volkswagen Offboard Diagnostic Information System.

Vehicle identification

The vehicle is identified by determining the vehicle basic features (type, model year, version, engine code) that can be detected automatically or partially automatically when a Gateway is present. Based on this data, a list of control modules and equipment that may be installed is created and the vehicle system test checks if these are installed or not.

Feedback

Error classification

Flash data

The flash data are sections of the programs that can be loaded for a vehicle system.

Flash memory

Hard drive whose data remains intact even when there is no power supply. In contrast to permanently programmed memory modules, a flash memory can be updated with a corresponding update program (using the Flash CD).

Gateway components list

A Gateway control module knows the vehicle systems installed in the vehicle. It monitors the vehicle systems and manages a status list. By checking the Gateway components list, for example, a vehicle system can be queried if its DTC memory is set, if it is coded or if communication is possible. The components list is evaluated during vehicle identification and leads to a more effective identification process.

Guided Fault Finding

In Guided Fault Finding, the diagnostic approach is integrated into an optimized process of vehicle identification, vehicle system test, test plan and function tests.

Guided Functions

Performing a vehicle specific function outside of GFF, for example, measuring

Basic Setting

In basic setting, control modules are adapted to the peripheral devices.

Basic features

A vehicle is identified based on the type, model year, version and engine code. Its equipment is then determined through a vehicle system test.

Hardware key, Hardware ID

Hardware features that are coded as a string of characters. The Hardware ID is a component of the device-based licensing.

Hotfix

Calibration

Precise adaptation of a tester (for example, current clamp) based on specifications and the correction of a measuring deviation through compensation of a systematic error.

Measurement

In measurements, you can complete measurements yourself whose results are displayed numerically or graphically on the tester. A multimeter and oscilloscope (DSO) are available.

Measured value block

A fixed group of measured values that are read from a vehicle system.

Mirror server

A software package that is stored locally on the dealer server, for example, and that maintains data for the VAS 505x update programs there. The dealer server is connected centrally and receives current updates from there. Within the workshop, each tester connected to the LAN retrieves the current programs automatically when switched on or explicitly when the "Network update" function in Administration is run.

Offline

There is no active connection to a communication network.

Online

Active connection with a communication network such as the workshop network, the Volkswagen dealer network or the Internet. See all Online connection.

Online log

A log that is sent to the vehicle manufacturer via the online connection.

Online connection

External connection such as one to the Internet or VW server.

Oscilloscope

Measurement and display unit for electrical signals that displays the progression of the signal strength over time (for example, oscillations).

D-PDU-API

The D-PUD-API is a standardized software interface for connecting diagnostic interfaces to the diagnostic software.

Platform

Protocols KW1281, KW2000, KW6000, UDS

The keyword protocols determine the exact process for exchanging data between a control module and the tester. Older control modules communication with KW1281. Newer control modules work with KW2000 or KW6000 (CAN diagnosis). ASAM control modules work with UDS. In vehicle OBD, the tester determines the control module's keyword protocol version automatically before selecting diagnostic functions for the control module.

Provider

A service provider that offers communication services such as telephone, wireless communication or Internet.

Proxy server

A proxy server is an exchange between clients and another network. It accepts requests from the client and forwards their data (sometimes modified or anonymously) to the original source (in another network such as the Internet). Proxies can temporarily store the data locally (cache) for additional access.

Test plan

Weighted sequence of test programs that the operating system suggests to the service technician for repairing the vehicle.

Test step

A self-contained unit in a function test.

RDID

Record Data Identifier. The Record Data Identifier decides on the data type. Via the Record Data Identifier, it is determined which data should be transferred.

Readiness code

8-digit binary code that indicates if all emissions- and safety-related diagnoses were run by engine management.

Control module

Electronic device for controlling and monitoring vehicle functions such as engine control module. Refer to ECU, vehicle system.

Test baseline

The developer version of a DIDB. It can be used either to expand or completely replace the productive data in the installation.

Touchscreen

A screen that also serves as an input device. By touching the contents of the screen, the device (such as a computer or cell phone) can be controlled.

TPS

Traversal test

This type of test identifies control modules and derives information from them that enables automatic vehicle identification. The test automatically cycles through the equipment network structures.

UDS

Unified Diagnostic Services; a standardized protocol in accordance with ISO 14229 for control module communication. Based on KW2000 for ASAM-ODX control modules.


Update

Software modification package for updating existing software to a higher version.

1. New version of the operating system that is downloaded from the CD-ROM.
2. New programming version of a vehicle system that is downloaded from the tester.

Things to Look out for!

P0016 Timing Fault




Lower Chain Sprocket incorrect position






Control Valve Checking




The piston -1- must be pushed in approximately 3 mm against the spring force. It must not become stuck while doing so.

Cylinder head cover



Remove in order 1 through 6.



Install New bolts in order 1 through 6.

Remove old sealant with flat blade scraper


Sealant D 154 103 a1

Front Radar Calibration Tools

VAS 6292



VAS 6430/3



HUN2018351

VAS 6430/1




VAS Scan Tool w/
ODIS Service



VAS 6190/2



T10113 or T20 Driver



Vas 6350

Used to set up lane change

